



HD-8TM *Series V*

Industrial Tub Grinder
Serial Number II00359 & Up

Manual 1: **Operating Instructions**





 **DURATECH[®]**
Clearing the Way for a Better Tomorrow



HD-8TM *Series V*

Industrial Tub Grinder
Serial Number II00359 & Up

Manual 1: **Operating Instructions**

DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of the HD-8TM Industrial Tub Grinder as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your unit.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals, and they should be located within easy access for periodic review.

 **DURATECH**[®] is a registered trademark of Duratech Industries International, Inc.

HD-8 is a trademark of Duratech Industries International, Inc.



 **DURATECH[®]**
Clearing the Way for a Better Tomorrow



FOREWORD



Foreword

All personnel must read and understand before operating unit

DuraTech Industries International Inc. (DuraTech Industries) has made every effort to assure that this manual completely and accurately describes the operation and maintenance of this Industrial Grinder as of the date of publication. DuraTech Industries reserves the right to make updates to the machine from time to time. Even in the event of such updates, you should still find this manual to be appropriate for the safe operation and maintenance of your machine.

This manual, as well as materials provided by component suppliers to DuraTech Industries are all considered to be part of the information package. Every operator is required to read and understand these manuals. All manuals should be located within easy access for troubleshooting and periodic review.

Appropriate use of the unit

This Industrial Grinder is designed to grind wood waste and other materials, including grass clippings, leaves, construction and demolition debris, tree branches and tree trunks. It is **NOT** designed to grind rocks, steel, concrete, or the like.

Operator protection

As with all machinery, care needs to be taken by the operator in order to insure the safety of the operator and those in the surrounding area.



WARNING: Operators and those observing the operation of the Industrial Grinder are required to wear head, eye, and ear protection. No loose clothing is allowed.



TABLE OF CONTENTS

Manual 1: Operating Instructions	1
Introduction	2
Purpose	2
Section 1: Safety	4
1.1 Safety-alert symbols	4
1.2 Operator - personal equipment	6
1.3 Machine safety labels	7
1.4 Shielding	10
1.5 Industrial Tub Grinder safety review	10
1.6 Thrown objects and operator safety	11
1.7 Service and maintenance	12
1.8 Personal protection equipment	13
1.9 Fire Prevention	13
1.10 Fire Extinguishers:	14
1.11 Important safety reminders	15
1.12 Towing	15
Section 2: Introduction	16
2.1 Description of the DuraTech Industrial Tub Grinder	16
2.2 Electronic governor	17
2.3 Rotor clutch	18
2.4 Torque limiter	18
2.5 Rotor	18
2.6 Screens	18
2.7 Tub	18
2.8 The conveyor system	19
2.9 Magnetic roller (optional)	19
2.10 Mill grate (optional)	19
2.11 Tub cover (optional)	19
2.12 Control Panel	20
2.13 Other operator controls	21



TABLE OF CONTENTS

Section 3: Operation 22

- 3.1 Pre-operation inspection 22
- 3.2 Starting the Industrial Tub Grinder 23
- 3.3 If the engine fails to start 23
- 3.4 Throttle operation 24
- 3.5 Automatic engine shutdown system 24
- 3.6 Normal shutdown procedure 25
- 3.7 Emergency shutdown procedure 26
- 3.8 Murphy System Operation 27
- 3.9 Parts of the electronic governor 28
- 3.10 Operation of the electronic governor 29
- 3.11 Calibration of the electronic governor 30
- 3.12 Adjusting the tub’s rotation speed 30
- 3.13 Raising the tub 31
- 3.14 Lowering the tub 32
- 3.15 Starting and stopping the discharge conveyor 32
- 3.16 Operating the grinder using the remote radio option 32
- 3.17 Grinding 35
- 3.18 Loading the tub 35
- 3.19 If lodging occurs while grinding 36
- 3.20 Grinding wet material 36
- 3.21 Preparing the HD-8 for transport 36
- 3.22 Preparing the HD-8 for operation after transport 37
- 3.23 Preparing the HD-8 for storage 38
- 3.24 Removing the HD-8 from storage 38
- 3.25 Installing a screen 39
- 3.26 Adjusting the conveyor belt tension 40
- 3.27 Adjusting the conveyor belt tracking 41
- 3.28 Sizing the tub drive chain 42
- 3.29 Adjusting tub chain tension 42
- 3.30 Ball type torque limiter 44
- 3.31 Checking for wear on the friction disc torque limiter 45
- 3.32 Engaging and adjusting the rotor clutch 46
- 3.33 Electro-hydraulic valve coil test 47
- 3.34 Electro-hydraulic valve calibration 49



TABLE OF CONTENTS

Section 4: Engine Maintenance	50
Section 5: General Maintenance	50
5.1 Welding procedure	50
5.2 Batteries	52
5.3 Lubrication	52
5.4 Pressure roller lubrication	57
5.5 Hydraulic system	58
5.6 Axle, wheels and tires	59
5.7 Hammermill maintenance	60
5.8 Fixed hammer maintenance and replacement	61
5.9 Swinging hammer replacement and maintenance	62
Section 6: Troubleshooting the HD-8	65
6.1 Troubleshooting the electronic governor system	65
6.2 General Troubleshooting	69
6.3 Troubleshooting Microtronics wireless remote controls	70
6.4 Troubleshooting Omnex Wireless Remote Controls	75
Appendix A: Warranty	78
Appendix B: SPECIFICATIONS	80
Appendix C: Operator Training Form	82
HD-8 Documentation Comment Form	84



HD-8TM *Series V*

Industrial Tub Grinder
Serial Number 1100359 & Up

Manual 1:

Operating Instructions



Introduction

This Industrial Grinder is designed to grind wood waste and other materials, including grass clippings, leaves, construction and demolition debris, tree branches and tree trunks. It is **NOT** designed to grind rocks, steel, concrete, or the like.

Purpose

The purpose of this owner's manual is to explain maintenance requirements and routine adjustments for the most efficient operation of your HD-8. There is also a trouble shooting section that may help in case of problems in the field. Any information not covered in this manual may be obtained from your dealer.



SPECIAL NOTE: When reference is made as to front, rear, left hand, or right hand of this machine, the reference is always made from standing at the rear end of the machine and looking toward the hitch. Always use serial number and model number when referring to parts or problems. Please obtain your serial number and write it below for your future reference.

MODEL: HD-8

SERIAL NO. _____

How to use this manual

Manual organization

This manual is organized into the following parts:

- **Manual 1: Operating instructions** explain how to set up, use and maintain the HD-8 Industrial Tub Grinder.
- **Manual 2: Parts reference** contains diagrams of each assembly with the number of each part identified. A key on the facing page contains a description of the part and the quantity used.

Dealer responsibilities

- Thoroughly review this section, "Dealer Responsibilities," and perform the tasks outlined. Also perform a daily pre-operation inspection as described in Section 3, "Operation."
- Upon delivery of the unit to the customer, it is the dealer's responsibility to conduct a training session on the safe operation of the unit for the primary operator(s). Dealer must also conduct a "walk-around" inspection of all safety instructional decals on the machine itself. Decals are illustrated in **Manual 2: Parts Reference**.
- When dealer is satisfied that the primary operators have read the operating instructions, and understand all information concerning the safe operation of the unit, sign and return the User Training Verification Form found in the HD-8 documentation packet.



NOTE: This form requires both the dealer's signature and the signatures of up to four primary operators.

- Complete and return the Delivery Notification Form found in the HD-8 documentation packet. Receipt of this form is required to activate the warranty. Appendix A provides details of the warranty.

Operator responsibilities

- The operator is responsible for his own safety.
- The operator is responsible for the safety of all others in the area.
- Review "Dealer Responsibilities," to verify that the machine has been prepared for use.
- Note the important safety information in the Foreword and in Section 1, "Safety."
- Thoroughly review sections 1 through 3 which explain normal operation of the machine, and section 4 and 5 which explain maintenance requirements. These sections will function as a textbook during the dealer-conducted training course that is required before use of the unit.
- When all primary operators have read the operating instructions and understand all information concerning the safe operation of the unit, the dealer will be required to sign the User Training Verification Form found the HD-8 documentation packet.



NOTE: This form requires both the dealer's signature and the customer's signature. The dealer is responsible for returning the signed form to DuraTech Industries.

- Manuals for certain third-party components are provided separately. The operator must also be familiar with their contents.
- Keep copies of all manuals in a readily-accessible location for future reference.



Section 1: Safety

Thank you for taking the time to read the operation and maintenance manual for the DuraTech Industries HD-8 Industrial Tub Grinder. Because your safety and that of others is of the utmost importance, you should familiarize yourself with this entire manual before operating this unit.

The HD-8 incorporates a number of third party products. For example, the engine, and clutch are third party products. More information about the operation and care of these products can be found in each product's respective manual(s). Before operating this unit, you should familiarize yourself with these manuals as well.

Safety is an ongoing job experience, and DuraTech Industries has made every effort to make sure that the HD-8 Industrial Tub Grinder provides operator security and comfort. DuraTech Industries encourages you to bring to our attention as quickly as possible any suggestions you may have concerning the safety of the equipment. DuraTech Industries is dedicated to enhancing the safety of the DuraTech Industries HD-8 Industrial Tub Grinder.

This unit is supplied with an operation and maintenance manual and this manual should be kept with the unit for periodic review by operational personnel.

Operators of the HD-8 are required to wear head, eye, and ear protection as well as clothing appropriate for the application. Individuals with loose clothing, unrestrained long hair, jewelry, or other accessories which may hang loosely away from the body should not be allowed on or near the machine.



WARNING: FAILURE TO COMPLY WITH SAFETY INSTRUCTIONS THAT FOLLOW WITHIN THIS MANUAL COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH. BEFORE ATTEMPTING TO OPERATE THIS MACHINE, CAREFULLY READ ALL INSTRUCTIONS CONTAINED WITHIN THIS MANUAL.

THIS MACHINE IS NOT TO BE USED FOR ANY PURPOSE OTHER THAN THOSE EXPLAINED IN THE OPERATOR'S MANUAL, ADVERTISING LITERATURE OR OTHER DURATECH WRITTEN MATERIAL PERTAINING TO THE HD-8.

1.1 Safety-alert symbols

Decals are illustrated in **Manual 2: Parts Reference**.

The safety decals located on your machine contain important and useful information that will help you operate your equipment safely.

To assure that all decals remain in place and in good condition, follow the instructions below:

- Keep decals clean. Use soap and water - not mineral spirits, adhesive cleaners and other similar cleaners that will damage the decal.
- Replace all damaged or missing decals. When attaching decals, surface temperature of the machine must be at least 40° F (5° C). The surface must be also be clean and dry.
- When replacing a machine component to which a decal is attached, be sure to also replace the decal.
- Replacement decals can be purchased from your DuraTech Industries dealer.



DuraTech uses industry accepted ANSI standards in labeling its products for safety and operational characteristics.



Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.

DANGER: Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations, typically for machine components that, for functional purposes, cannot be guarded.



DANGER:
Signal word - White Lettering/Red Background
Safety Alert Symbol - White Triangle/Red Exclamation Point

WARNING: Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



WARNING:
Signal word - Black Lettering/Orange Background
Safety Alert Symbol - Black Triangle/Orange Exclamation Point

CAUTION: Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



CAUTION:
Signal word - Black Lettering/Yellow Background
Safety Alert Symbol - Black Triangle/Yellow Exclamation Point

This manual uses the symbols to the right to denote important safety instructions and information.

The **DANGER**, **WARNING** and **CAUTION** symbols are used to denote conditions as stated in the text above. Furthermore, the text dealing with these situations is surrounded by a box with a white background, will begin with **DANGER**, **WARNING**, or **CAUTION**.

The **INFORMATION** symbol is used to denote important information or notes in regards to maintenance and use of the machine. The text for this information is surrounded by a box with a light grey background, and will begin with either **IMPORTANT** or **NOTE**.





1.2 Operator - personal equipment

THE OPERATOR

Physical Condition

You must be in good physical condition and mental health and not under the influence of any substance (drugs, alcohol) which might impair vision, dexterity or judgment.

Do not operate a **HD-8** when you are fatigued. Be alert - If you get tired while operating your **HD-8**, take a break. Fatigue may result in loss of control. Working with any farm equipment can be strenuous. If you have any condition that might be aggravated by strenuous work, check with your doctor before operating

Proper Clothing



Clothing must be sturdy and snug-fitting, but allow complete freedom of movement. Avoid loosefitting jackets, scarfs, neckties, jewelry, flared or cuffed pants, unconfined long hair or anything that could become entangled with the machine.



Protect your hands with gloves when handling flail and sections. Heavyduty, nonslip gloves improve your grip and protect your hands.



Good footing is most important. Wear sturdy boots with nonslip soles. Steel-toed safety boots are recommended.




To reduce the risk of injury to your eyes never operate a **HD-8** unless wearing goggles or properly fitted safety glasses with adequate top and side protection.



Tractor noise may damage your hearing. Always wear sound barriers (ear plugs or ear muffers) to protect your hearing. Continual and regular users should have their hearing checked regularly.


1.3 Machine safety labels

The safety decals located on your machine contain important information that will help you operate your equipment. Become familiar with the decals and their locations.

	<p>DANGER: OBJECTS THROWN BY MACHINE DO NOT OPERATE WITHOUT WEARING SAFETY GLASSES AND A HARD HAT. KEEP UNAUTHORIZED PERSONNEL OUT OF THE GRINDING AREA</p>
---	--




6500118

	<p>DANGER: ROTATING PART HAZARD, STAY OUT OF TUB WHEN ENGINE IS RUNNING.</p> <ol style="list-style-type: none"> KEEP OTHERS AWAY. PLACE ALL CONTROLS IN NEUTRAL, STOP ENGINE, REMOVE KEY, AND WAIT FOR ALL MOVING PART TO STOP BEFORE SERVICING, ADJUSTING, REPAIRING, UNPLUGGING, OR ENTERING THE TUB FOR ANY REASON. DISCONNECT DRIVELINE ON PTO MODELS.
---	--



6500212

	<p>DANGER: ELECTROCUTION HAZARD TO PREVENT SERIOUS INJURY OR DEATH FROM ELECTROCUTION:</p> <p>STAY AWAY FROM POWER LINES WHEN OPERATING BOOM LOADER, FOLDING AND RAISING CONVEYORS, AND TRANSPORTING ON ROADS.</p> <p>THIS MACHINE IS NOT GROUNDED, ELECTROCUTION MAY OCCUR WITHOUT DIRECT CONTACT.</p>
---	--



6500216



WARNING: FOR YOUR PROTECTION AND SAFETY OF OTHERS, FOLLOW THESE SAFETY RULES

1. READ AND UNDERSTAND OPERATORS MANUAL BEFORE OPERATING MACHINE.
2. PLACE ALL CONTROLS IN NEUTRAL, STOP ENGINE, REMOVE IGNITION KEY, LOCK OUT POWER SOURCE, AND WAIT FOR ALL MOVEMENT TO STOP BEFORE SERVICING, ADJUSTING, REPAIRING, OR UNPLUGGING.
3. READ AND UNDERSTAND ALL DECALS ON MACHINE FOR YOUR SAFETY.
4. KEEP ALL SHIELDS IN PLACE WHILE MACHINE IS IN OPERATION.
5. KEEP HANDS, FEET, HAIR, AND CLOTHING AWAY FROM MOVING PARTS.
6. KEEP OTHERS AWAY FROM MACHINE WHILE IN OPERATION.
7. INSTALL SAFETY LOCKS BEFORE TRANSPORTING, OR WORKING BENEATH COMPONENTS.
8. DO NOT ALLOW RIDERS AT ANY TIME.
9. DO NOT LEAVE MACHINE UNATTENDED WHILE ENGINE IS RUNNING.
10. KEEP ALL HYDRAULIC LINES, COUPLINGS, AND FITTINGS FREE OF LEAKS DURING OPERATION.
11. KEEP AWAY FROM OVERHEAD ELECTRICAL LINES. ELECTROCUTION CAN OCCUR WITHOUT DIRECT CONTACT.
12. REVIEW SAFETY INSTRUCTIONS PERIODICALLY.

WARNING	ADVERTENCIA
FOR YOUR PROTECTION AND SAFETY OF OTHERS, FOLLOW THESE SAFETY RULES.	PARA SU PROTECCIÓN Y LA SEGURIDAD DE OTROS, OBSERVE ESTAS NORMAS DE SEGURIDAD.
<ol style="list-style-type: none"> 1. Read and understand operators manual before operating machine. 2. Place all controls in neutral, stop engine, remove ignition key, lock out power source, and wait for all motion to stop before servicing, adjusting, repairing, or unplugging. 3. Read and understand all decals on machine for your safety. 4. Keep all shields in place while machine is in operation. 5. Keep hands, feet, hair, and clothing away from moving parts. 6. Keep others away from machine while in operation. 7. Install safety locks before transporting, or working beneath components. 8. Do not allow riders at any time. 9. Do not leave machine unattended while engine running. 10. Keep all hydraulic lines, couplings, and fittings free of leaks during operation. 11. Keep away from overhead electrical lines. Electrocutation can occur without direct contact. 12. Review safety instructions periodically. 	<ol style="list-style-type: none"> 1. Lea y comprenda el manual del operador antes de operar la máquina. 2. Coloque todos los controles en punto neutro, apague el motor, quite la llave de encendido, cierre la alimentación de electricidad y espere a que se detenga todo el movimiento antes de proceder al servicio, ajuste, reparación o desenchufado. 3. Lea y comprenda todas las etiquetas adheridas a la máquina para su seguridad. 4. Mantenga todas las defensas en su lugar mientras la máquina está en funcionamiento. 5. Mantenga las manos, pies, cabello y ropa lejos de las partes en movimiento. 6. Mantenga a los otros personas alejados de la máquina en funcionamiento. 7. Instale los cerrojos de seguridad antes de transportar o trabajar debajo de las componentes. 8. No permita que otros operen la máquina en ningún momento. 9. No deje la máquina sin supervisión con el motor encendido. 10. Aleje de todas las líneas hidráulicas, acoplamiento y conexiones con fugas durante el funcionamiento. 11. Póngase alejado de las líneas eléctricas elevadas. Puede producirse la electrocución sin contacto directo. 12. Revise las instrucciones de seguridad con frecuencia.

6500208



WARNING: TO PREVENT SERIOUS INJURY OR DEATH:

DO NOT WALK UNDER CONVEYOR AT ANY TIME. STAY CLEAR OF CONVEYOR DURING OPERATION, RAISING, AND LOWERING. LOWER CONVEYOR FULLY BEFORE SERVICING.

KEEP OTHERS AWAY.

WARNING	ADVERTENCIA
	PELIGRO DE CINTA TRANSPORTADORA ELEVADA
OVERHEAD CONVEYOR HAZARD To prevent serious injury or death: Do not walk under conveyor at any time. Stay clear of conveyor during operation, raising, and lowering. Lower conveyor fully before servicing. Keep others away.	No caminar por debajo de la cinta transportadora en ningún momento. Manténgase alejado de la cinta transportadora durante el funcionamiento, al subir y al bajar. Baje completamente la cinta transportadora antes de proceder al servicio. Mantenga alejados a otros personas.

6500214



WARNING: THROWN OBJECT HAZARD, TO PREVENT SERIOUS INJURY OR DEATH DO NOT RAISE TUB WHEN ROTOR IS TURNING.

1. DISENGAGE ROTOR AND ALLOW TO COME TO A COMPLETE STOP.
2. BE CERTAIN THAT ALL PERSONNEL ARE CLEAR OF MACHINERY AREA.
3. RAISE TUB TO FULL VERTICAL POSITION.
4. STOP ENGINE AND REMOVE KEY BEFORE APPROACHING TUB AND ROTOR AREA.



6500209



WARNING: HIGH-PRESSURE FLUID HAZARD, TO PREVENT SERIOUS INJURY OR DEATH:

- RELIEVE PRESSURE ON SYSTEM BEFORE REPAIRING OR ADJUSTING OR DISCONNECTING.
- WEAR PROPER HAND AND EYE PROTECTION WHEN SEARCHING FOR LEAKS. USE WOOD OR CARDBOARD INSTEAD OF HANDS.
- KEEP ALL COMPONENTS IN GOOD REPAIR.



6500220



CAUTION: KEEP WHEEL BOLTS TIGHT



6500042



1.4 Shielding

This Industrial Tub Grinder is equipped with heavy-duty shielding at major points of potential injury. All Shields should be kept in place during operation. Bodily injury may occur if the unit is operated without shields.



WARNING: Shields are installed for your protection and to keep material off machine parts. Do not operate this Industrial Tub Grinder without shields in place.

1.5 Industrial Tub Grinder safety review



WARNING: Before attempting to operate your Industrial Tub Grinder, carefully read and follow instructions given below and contained elsewhere in this manual.

Each and every aspect of the **DuraTech Industries HD-8 Industrial Tub Grinder** should be reviewed by each operator on a frequent basis. Safety systems are in place that result in direct operator security.

- Keep all foreign objects including rocks, pieces of metal and other incompressibles out of the tub and away from the mill. Foreign objects may result in personnel injury or damage to the machine. A foreign object is any object which the unit is not designed to grind.
- Allow only responsible, properly instructed individuals to operate machines. Carefully supervise inexperienced operators.
- **Never operate the unit without all safety features, including shields, in place and in operating condition.**
- Make no modifications to this equipment unless specifically requested or recommended by DuraTech Industries.
- Tighten or replace any loose or cracked bolts, chains, hoses or connections.
- Check overhead for electrical power lines or other obstructions and be certain there is adequate clearance.
- Allow no one on the Industrial Tub Grinder at any time during operation.
- Unauthorized personnel should stay out of the grinding area.
- Always perform the pre-operation inspection before operating this machine.
- Ensure rotor is at a complete stop and engine is shut down before any performing any maintenance.
- **Never grab rope, cable, twine or similar material hanging out of the tub while the tub grinder is running.**



WARNING: Loose clothing, necklaces and similar items are easily caught in moving parts. Avoid the use of these items if possible. Keep long hair confined. Keep hands, feet and clothing away from power driven parts.



1.6 Thrown objects and operator safety

An operational characteristic of all grinders is that objects may be thrown out of the hopper. Thrown objects may present a safety hazard to persons in the area. This section is to inform the operator of this characteristic, and what can be done to reduce the risk of injury to the operator and persons in the area. Keep all observers away from the machine.

Figure 1.1 shows an object being hit as the hammer is on the upswing. A general pattern for where thrown objects may land is shown in Figure 1.2.




Figure 1.1



NOTE: The difference in the size of the area for side A versus side B. Side B is larger.

Dimensioning the size of this area is not practical. The distance a thrown object may travel is dependent on several conditions, including, but not limited to, rotor speed and diameter, condition of the hammers, style of hammers, object mass, object shape, amount of material in the tub, and how the hammer strikes the object.




Figure 1.2



The amount of material in the tub can dampen or stop the object's potential flight. Keeping the tub full will reduce the risks. Filling the tub at least 1/2 full when starting will reduce the risk. Using a geyser plate can help reduce thrown objects. A risk may arise when the tub is being emptied, such as at the end of the grind. Running the engine at slower speeds when starting or finishing the grind will also help, especially slowing down when emptying the tub. Keeping the tub covered with DuraTech Industries Tub Covers will also reduce the risk of potential injury or property damage. Use of a Tub Cover will not reduce the area over which thrown objects may fall, but it does reduce the percentage of objects thrown from the tub.



WARNING: To minimize the potential risk of injury or property damage, the operator must:

- a) Place side B towards open areas, away from property and people.
- b) Load the grinder from side A with a loader equipped with an enclosed cab.
- c) Keep observers out of the area.
- d) Wear a hard hat and safety glasses, at a minimum, and require that any other persons in the area are similarly equipped.
- e) If the optional tub cover is installed on the machine, the operator should keep the Tub Cover over the tub as much as possible while grinding. While grinding, the Tub Cover should be raised only when adding material to the tub, and then the Tub Cover should only be raised enough to allow the new materials to be placed in the tub.

1.7 Service and maintenance



CAUTION: The stored up energy in the rotor causes it to rotate long after the engine rotor clutch has been disengaged. Before performing any maintenance on the machine or getting into the tub, be sure rotor and all moving parts have come to a complete stop. Shut off engine and remove the key.

Before working on or near the Industrial Tub Grinder for any reason such as servicing, inspecting or unclogging the machine:

- Follow the normal shutdown procedure found on page 25 of this manual.
- If the unit is still attached to a towing vehicle, place the towing vehicle's transmission in park and set the parking/emergency brake.



- Relieve all pressure in the hydraulic system before disconnecting hydraulic lines or performing work on the system. Make sure all connections are tight and the hoses and lines are in good condition before applying pressure to the system.



WARNING: Hydraulic fluid escaping under pressure can be invisible and have enough force to penetrate the skin. When searching for a suspected leak, use a piece of wood or a cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.

When replacing any part on your Industrial Tub Grinder, be sure to use only DuraTech authorized parts.

1.8 Personal protection equipment

Operators and authorized observers of the Industrial Tub Grinder are required to wear head, eye, and ear protection. No loose clothing is allowed.

1.9 Fire Prevention

Grinding wood, hay, and other products in a tub grinder produces a large amount of potentially combustible material. The risks of fire can be significantly reduced with proper operating and maintenance procedures. This does include frequent removal of dust, debris, and other combustible materials.

Most of the products that are ground are dry and the grinding process can produce fine, dusty material. The grinding process can produce heat and the spinning rotor will circulate air within the grinding chamber. For a fire to start, fuel, oxygen and heat in sufficient quantity, must be present. During normal operation and with a properly maintained tub grinder, the material being ground will move through the grinding chamber so quickly that it doesn't have a chance to heat up sufficiently to start a fire. Also, the rapid rate that a tub grinder can pile material will quickly smother small hot spots that might occur during normal grinding operations. Keeping the material moving through the machine and across the top of the rotor is important to keep frictional heating of the material to a minimum.

NEVER leave the vicinity of the unit with the engine running.

PROPER OPERATION OF THE TUB GRINDER:

- Do not grind materials any finer than necessary. Finely ground materials will produce more dust and increase the risk of fire. If finely ground materials are required, it is better to grind the materials coarse first with large opening screens installed in the grinder and then regrind them to the desired consistency by installing smaller opening screens in the grinder. Be especially cautious when grinding materials that can burn easily.



- When filling the tub grinder during start-up begin by filling the rear of the tub and avoid placing materials on the spinning rotor. When material begins to fall over the rotor, set the governor control on “Manual” and rotate the tub slowly while continuing to fill the tub. Use the tub cover to control thrown objects as much as possible. When the tub is 1/2 to 2/3 full, the governor control can be set to “auto” and grinding operations can resume normally. Do not allow the tub to stop for any significant amount of time with material over the rotor to minimize frictional heating.
- Do not smoke when working with combustible materials.

REMOVAL AND CLEANING INSTRUCTIONS:

- Clean the engine compartment daily or more often if conditions require it be done more frequently. When cleaning the engine compartment, always clean the top of the engine and the areas around exhaust manifolds, exhaust plumbing and turbochargers.
- Check the rotor box for debris built up around the rotor. Remove material that may be packed tight near the bearings, on shaft or other rotating components because it will become hot due to friction.
- At shutdown, always clean and remove all dust, debris, or combustible material off the entire grinder. Use high-pressure air or water if necessary. Always move the grinder and all other equipment away from the ground material pile before leaving the job site in case of smoldering combustion in the ground material.

TUB GRINDER MAINTENANCE:

- Repair any fuel or hydraulic leaks as quickly as they are discovered. Clean up spills immediately. Fuel or oil soaked materials can contribute significantly to the rapid spreading of a fire once it has begun.
- Inspect all electrical wiring periodically. Any chafed or damaged wires should be repaired immediately. Keep all electrical connections tight to prevent arcs or sparks.
- Contact between the rotor and any stationary component of the grinding chamber such as contact between the hammers and the screens must be corrected immediately.

1.10 Fire Extinguishers:

Fire extinguishers are provided on this Duratech grinder in the unlikely event that a fire does start on the grinder. An extinguisher is located on both sides of the machine near the front of the engine compartment. The extinguishers are ABC dry chemical extinguishers that are appropriate for use with all materials normally encountered on a tub grinder.

If a fire does start, **CALL THE LOCAL FIRE DEPARTMENT IMMEDIATELY.** Then, use the fire extinguisher if you feel confident that you can extinguish the fire. A 10# extinguisher will last about 15-20 seconds and a 20# extinguisher will last about 20-24 seconds, so they will not stop a large fire.



When using a fire extinguisher, use the P A S S method:

- Approach the fire with the wind at your back.
- **Pull the pin,**
- **Aim the spout,**
- **Squeeze the trigger, and**
- **Sweep along the base of the fire from about 6-8 feet away.**

Read the label on your extinguisher now, most extinguishers have descriptions of this method, and an estimated working time.

If an extinguisher is only partially used, the dry chemical will jam in the seals, allowing the extinguisher to lose its pressure charge in less than an hour, making it useless to you. It must be recharged before placing it back on the machine. Have the extinguisher recharged today; a fire will not wait for you to recharge your extinguisher tomorrow!

Fire extinguishers should be inspected and recharged by a professional at least annually to keep them at optimum performance! A “verification of service” collar that confirms the month and year of service should be attached to the neck of the container to confirm when the extinguisher was last serviced.

1.11 Important safety reminders

Always follow basic safety precautions when using this unit to reduce the risk of injury.



NEVER perform maintenance in the tub, under the machine, on the conveyor, or other moving part of the machine without first shutting off the engine and removing the key.

Unauthorized personnel should stay out of the grinding area. Flying debris can injure inattentive personnel.



NEVER climb on the machine, crawl under the machine, or enter the tub when the engine is running or the machine is in operation.

1.12 Towing

Check all lights, brakes and hitch connections before towing. Check your state laws regarding the use of lights, safety chains, moving wide loads on public roads, and other possible requirements.

Use caution when traveling on public roads, rough or winding roads, or steep terrain.

See Section 3.21 for more information about preparing the unit for transport.




Section 2: Introduction

2.1 Description of the DuraTech Industrial Tub Grinder

The Industrial Tub Grinder is designed to grind wood waste, green waste, construction and demolition debris, tree branches and trunks, compostables and mulch. The unit incorporates a number of basic features including the rotating tub, the electronic governor, the rotor and hammer assemblies, the tub chain and drive assemblies, the clutch and torque limiter assemblies, discharge conveyor, and the axle and hitch assemblies.


Material is fed into the tub of the unit by appropriate means, such as a wheel loader. As the tub rotates, the material is exposed to the rotating hammers. The hammers then grind the material before the material is discharged by the discharge conveyor.





2.2 Electronic governor

The Model RCB93 Electronic Governor regulates the speed at which the tub rotates. The electronic governor has two modes of operation, the Engine (Auto) mode and the Tub (Manual) mode. The Engine (Auto) mode is the preferred mode of operation and should be used whenever possible.



electronic governor



IMPORTANT: Except when calibrating or trouble shooting the electronic governor always use the Engine (Auto) mode of the electronic governor.

Engine (Auto) Mode

When the electronic governor is switched to the Engine (Auto) mode, it is monitoring the rotation speed of the engine. The hydraulic flow to the tub drive mechanism is regulated proportionally to the engine speed. When the engine begins to lug down, the hydraulic oil flow is reduced which in turn slows down the tub rotation. With proper calibration, the engine will only lug down to its optimum horsepower RPM and the tub rotation will be varied proportionally to keep the engine at this RPM. The result is a nearly constant load on the engine, which will maximize grinding efficiency. See section 3.11 (pg. 30) for calibration instructions.

Tub (Manual) Mode

In this mode the tub speed is constant and it will not change to match varying load conditions



2.3 Rotor clutch

The clutch engages and disengages the rotor shaft. Engagement and disengagement of the clutch is accomplished through the use of a manually operated lever that is located on either side at the front of the engine.

2.4 Torque limiter

The torque limiter is installed to prevent or reduce damage to the engine and clutch in the event of an instantaneous stop due to a rotor overload.

2.5 Rotor

The rotor is the heart of the grinder. The standard rotor contains swinging hammers and is used for general grinding. When larger objects such as large logs are to be ground, fixed hammers are used.

2.6 Screens

The DuraTech Industries HD-8 industrial tub grinders come equipped from the factory with one screen. The factory equipped screens is a 4" diameter hole screen.

The size of the ground material is determined by the diameter of the screen holes. As the diameter of the screen holes becomes larger, the size of the ground material increases.

As a general rule, use the largest screen capable of doing the job.

Round perforated screens are available with 2", 3", 4" and 5" diameter holes in 1/2" thick steel. A 6" x 7" demolition screen is also available. The demolition screen is used for size reduction on construction debris, demolition debris and wet materials.

2.7 Tub

Material to be ground is loaded into the tub using a wheel loader, or other suitable methods. As the tub rotates, the material is fed into the rotor. The faster the tub rotates, the more material is exposed to the rotor, and the greater the load on the engine. The tub's rotation speed is controlled by the electronic governor. To reduce the amount of material thrown by the rotor during operation, the tub should be kept 1/2 to completely full during grinding operation.

The HD-8's tub can be tilted 50 degrees for access to the rotor, screens, and drive line. The tub has an electronic safety switch that will not allow the tub to be raised with the rotor turning. The switch provides feedback to the operator through two indicator lights which are located on the control panel. If the green indicator light is on, the operator may tilt the tub. Conversely, if the red indicator light is on, the safety switch will prevent the operator from tilting the tub.



2.8 The conveyor system

The conveyor system on the HD-8 consists of a discharge conveyor. The discharge conveyor moves the ground material away from the unit. The conveyor is run by one hydraulic orbit motor which is turned on and off with one control switch. This control switch is located in the operations control panel on the front of the machine. The discharge conveyor can be folded for transport by operating a switch located at the operations control panel.

2.9 Magnetic roller (optional)

An optional roller can be added to the unit which removes nails and other iron products from the ground material.

2.10 Mill grate (optional)

An optional grate can be installed above the rotor to regulate the amount of material entering the rotor chamber. The mill grate can be used for general grinding. The hammer spacing in the rotor must require change for this option.

2.11 Tub cover (optional)

An optional tub cover may be added to the unit that helps to reduce the the amount of material ejected from the tub while grinding.



figure 2.1
engine control panel





figure 2.2
operations control panel



2.12 Control Panel

The engine control panel is located at the front left side of the engine. Controls include; engine start, engine kill button, tattle tale/engine start button. Gauges include; engine temperature, engine oil pressure, engine amp, tachometer, fuel, system pressure and tub pressure.



The operations control panel is located at the front of the machine. It can be locked in 3 positions. Controls include; conveyor on/off switch, tub operation switch (fwd - rev), conveyor fold switch, platform raise/lower switch, radio remote on/off switch, tub cover up/down, tub cover in/out, electronic governor, emergency stop button and rotor status indicator.

2.13 Other operator controls

Tub lock pin

The tub lock pin is located on the right hand side of the machine under the tub. The tub lock pin must be removed before tilting the tub and replaced after the tub is lowered.


Clutch lever

The clutch lever is placed on either side of the machine near the radiator shield shown in figure 2.1. These levers allow the operator to engage or disengage the rotor.

Radio remote control unit (optional)

The radio remote control unit allows the operator to remotely start and stop the tub, change the tub's direction of rotation to forward or reverse and perform an emergency stop. If the optional tub cover is fitted to the machine, it also may be operated by the radio remote control.

NOTE: See also section 3.16, "Operating the grinder using the remote radio option"





Section 3: Operation

3.1 Pre-operation inspection

Read and have a thorough understanding of the operator's manual, especially the sections pertaining to machine operation and safety. Also make sure that anyone who will assist you in the operation or maintenance of this machine understands how the machine operates.

Before operating the HD-8 Industrial Tub Grinder, perform an inspection that includes the following items. As each task is performed, check or initial the adjacent box.

- Check lubrication points and lubricate as recommended in the general maintenance section of this manual.
- Make sure that the machine is properly adjusted. Procedures for making adjustments to various HD-8 components can be found later in this section.
- Check engine oil level and coolant level, and add or change as necessary. Also look for oil or coolant leaks and repair as necessary.
- Check the hydraulic oil level, and add or change the hydraulic oil as necessary. Also check the hydraulic system for leaks.



WARNING: Hydraulic fluid escaping under pressure can be invisible and have enough force to penetrate the skin. When searching for a suspected leak, use a piece of wood or a cardboard rather than your hands. If injured, seek medical attention immediately to prevent serious infection or reaction.

- Check the air cleaner service indicator. If the red indicator is visible, service the air cleaner.
- Check for buildup of debris around the radiator, turbocharger, manifolds, air intake and moving parts. Remove the debris before operating the unit. Buildup of debris may result in fire.
- Inspect belts for cracks, breaks, or other damage.
- Inspect wiring for loose connections and for worn or frayed wires.
- Check the fuel supply, and drain any water from the water separator.
- Visually examine the rotor to see if any parts show excessive wear. These parts include shaft, plates, rods, hammers and movable plate. Replace or repair any worn parts before operating the unit.
- Check the screens for wear. Also check the screen hold downs for wear and tightness. Replace or repair any worn parts before operating the unit.
- Visually examine the rotor bearings and the mounting bolts and check all bearings for wear. Replace or repair any worn parts before operating the unit.
- Make sure that all shields and guards are in place and in operating condition.
- Check clutch adjustment.



3.2 Starting the Industrial Tub Grinder



NOTE: The engine will start easier at cool temperatures by use of a starting aid. A block heater or other means can be used to warm the engine.



NOTE: Do not crank the engine for more than 30 seconds. Allow the starter motor to cool for two minutes before cranking again.

Check engine manufacturers recommendations before starting the engine, and follow their recommendations where applicable.

Check for **DO NOT OPERATE** or similar warning tags.

Do not move any controls if such tags are on the machine.

To start the engine, perform the following steps:

1. Perform the pre-operation inspection.
2. Disengage the clutch lever.
3. Set the throttle to approximately half engine speed.
4. Shout the word “**CLEAR**”.
5. Press and hold down the Tattle-tale button.
6. Turn the key to the start position and release it when the engine starts.
7. Release the Tattle-tail button 10 seconds after the engine starts. If the oil pressure does not rise within ten seconds after starting, stop the engine and make the necessary repairs.
8. Reduce the engine speed to a low idle. Allow the engine to idle for 3 to 5 minutes, or until the water temperature gauge indicator has begun to rise. The engine should run smoothly at low idle.
9. Make another walk-around inspection checking the engine and hydraulic system for fluid leaks.
10. Follow the engine manufacturers recommendations for the care and maintenance of a new engine.



NOTE: See also section 3.16, “Operating the grinder using the remote radio option”



3.3 If the engine fails to start

If the engine doesn't start on the first try, perform the following steps:

1. Wait two minutes before attempting to restart.
2. Shout the word "CLEAR".
3. Depress and hold the Tattle-tale button and turn the key clockwise to crank the engine. Do not crank for more than 30 seconds.
4. If the engine fails to start contact a qualified diesel mechanic for further advice.

3.4 Throttle operation

To increase throttle speed slowly, turn the throttle knob counter clockwise rather than pulling the knob straight out.

To decrease throttle speed, turn the knob clockwise.

For emergency slowdown, depress and hold the lock button in the center of the throttle knob and push the throttle knob straight in.

3.5 Automatic engine shutdown system

The engine will automatically shut down if it overheats or if engine oil pressure is inadequate. If this happens, perform the following steps:

1. Check the engine oil level.
2. Inspect the radiator and radiator screens. Clean if necessary.
3. Check tension and condition of the fan belt.
4. Allow engine to cool and check the coolant level.
5. Attempt to restart engine following the normal starting procedure.
6. If the engine will not continue running, contact a qualified mechanic.



3.6 Normal shutdown procedure



NOTE: Stopping the engine immediately after it has been working under load can result in overheating and accelerated wear of the engine components. Allow the engine to cool down before stopping. Avoiding hot engine shutdowns will maximize turbocharger, shaft, and bearing life.

Use the following procedure to shut down the Industrial Tub Grinder under normal operation:

1. Disengage the tub drive.
2. Allow the tub conveyor belts to run until empty.
3. Disengage the rotor clutch.
4. Disengage the conveyor drive.
5. Follow the engine manufacturer's recommendations for cooling the engine; generally, this consists of running the engine at 1/2 speed or idle for 5 minutes.
6. Shut off the engine and remove the key.
7. Note the service hour meter reading, and perform periodic maintenance as required.
8. Repair any leaks, perform minor adjustments, tighten loose bolts, etc.




NOTE: See also section 3.16, "Operating the grinder using the remote radio option"



3.7 Emergency shutdown procedure

figure 3.1
emergency shutdown
button tattle-tale button
and emergency stop
button



IMPORTANT: Emergency shutoff controls are for **EMERGENCY** use Only. **DO NOT** use the emergency shutoff controls for normal stopping procedure.

1. Push in the emergency stop button or the emergency shutdown button located on the control panel and remove key.



NOTE: The emergency stop button found on the operating control panel will have to be reset before restarting the engine.




NOTE: See also section 3.16, “Operating the grinder using the remote radio option”



3.8 Murphy System Operation

There are 6 terminals on the bottom of the 518APH Murphy relay. 12VDC power is supplied from the key switch from the IGN terminal when the key is in the run position. The power passes through a panel-mounted fuse and enters the Murphy relay at terminal [B]. When the override button is depressed, power is available at the [NC] terminal and at the [SW1] terminal. There is a resistor between [NC] and [SW1]. Power returns to the relay through terminal [SW2]), which keeps the relay latched electrically (Closed Loop circuit). The fifth terminal is the ground [G] terminal. The sixth terminal found only on the 518APH is the [NO] terminal which will be energized when the Murphy relay is unlatched and the key switch is in the run position. The sixth terminal [NO] is not used on the DuraTech Industries tub grinders.



On the Cummins engine, power must be supplied to the fuel supply valve in order for the engine to run. The fuel supply valve is connected to the [NC] terminal of the Murphy relay so, power is only supplied to the fuel valve when the Murphy relay button is pushed in and the key switch is in the run position. The oil pressure SWITCHGAGE, the water temperature SWITCHGAGE, the tub tilt interlock system, and all engine kill buttons are connected to the Closed Loop circuit which is connected from [SW1] to [SW2] on the Murphy relay. Any of the above controls can shut the engine down by connecting the Closed Loop circuit to “ground” (usually a local frame ground). This will “short circuit” the power that is emitted from [SW1] directly to ground and no power will return to [SW2]. This will cause the Murphy relay to unlatch and power will be shut off to the fuel supply valve, causing the engine to shutdown. The resistor in the Murphy relay reduces the voltage so arcing is minimized when a shutdown signal is activated. Also, any “inadvertent ground” in any wire of the Closed Loop or loss of power in the Closed Loop will cause the Murphy Relay to unlatch and the engine will shut down.



3.9 Parts of the electronic governor

For an illustration of the electronic governor, see figure 3.2

FUSE LIGHT

This light is on whenever the electronic governor is receiving power.

SENSOR LIGHT

This light is on whenever the electronic governor is receiving an adequate input signal from the sensor. For the sensor light to work you must have the clutch engaged, the engine running at grinding RPM, and the Mode Switch must be switched to the engine position.

SPEED LIGHTS

These lights provide a relative indication of how fast your tub should be turning based on the output signal that the electronic governor is sending to the electro-hydraulic valve.

MODE SWITCH

The mode switch has three possible positions. The off position which turns the electronic governor off and two other positions which correspond to the tub (manual) and engine (auto) modes of operation. In the “tub (manual)” position the tub will rotate at a constant speed based on the settings of the Tub Limit Knob (Tub Speed Knob). The “engine (auto)” position uses all the functions of the Electronic Governor. The maximum tub speed will be limited by the Tub Limit Knob (Tub Speed Knob), and the engine load will be controlled by the Engine Load Knob.

TUB LIMIT KNOB (TUB SPEED KNOB)

This knob sets the maximum speed at which the tub will rotate in both the tub (manual) and engine (auto) modes. In the engine (auto) mode tub speed will vary between zero and this setting depending on the engine load.

ENGINE LOAD KNOB

This knob is used only in engine (auto) mode. It controls the load placed on the engine. Turning the knob clockwise decreases engine load, and turning the knob counterclockwise increases the engine load.




NOTE: Decreasing engine load may help if engine overheats.

RANGE SWITCH

This switch is a coarse adjustment for the engine load knob and can be switched to a H-high, M-medium or L-low setting.



figure 3.2
electronic governor
controls



3.10 Operation of the electronic governor

Engine (Auto) mode



IMPORTANT: Except when calibrating or trouble shooting the electronic governor always use the engine (auto) mode of the electronic governor.

In engine (auto) mode, the electronic governor monitors the rotation speed of the engine. The hydraulic flow to the tub drive mechanism is regulated in proportion to the engine speed. As the engine speed slows, the electronic governor decreases the hydraulic flow which slows down the tub's rotation. Conversely, as the engine speed increases, the electronic governor increases the hydraulic flow which speeds up the tub's rotation. This allows the electronic governor to automatically control the feed rate keeping the engine running within the governor's optimum power zone. When the load on the grinding rotor begins to lug the engine, the governor automatically reduces the tub's rotation speed in proportion to the load. The result is nearly a constant load on the engine, which maximizes the grinding efficiency.

The range of rotor speeds for which the electronic governor will regulate the hydraulic flow is determined by the setting of the engine load knob. For example, turning the engine load knob counter clockwise will increase the load on the engine by keeping the tub engaged to a lower engine RPM.

With proper calibration, the engine will only load down to its optimum horsepower RPM, and the tub's rotation speed will be varied proportionally to keep the engine at this RPM.

Tub (Manual) mode

In tub (manual) mode, the electronic governor performs as a simple tub speed control. In this mode the tub speed is constant and it will not change to match varying load conditions.



3.11 Calibration of the electronic governor

To calibrate the electronic governor, perform the following steps:

1. Begin calibration procedure with HD-8 Tub Grinder completely shutdown. Place the MODE switch in the OFF position and the RANGE switch in the H-High position. Rotate the TUB SPEED KNOB fully clockwise toward the rabbit position. Turn the ENGINE LOAD KNOB fully clockwise, and switch the MODE switch to ENGINE (Auto) Position.
2. Verify that rotor clutch is disengaged. Inspect machine to verify that all personnel are clear of the machine.
3. Start engine and run the grinder at about 1/2 throttle to allow the hydraulic system to warm up before calibrating the RCB93 Electronic Governor.
4. When the system has reached operating temperature, throttle the engine to under 1000 RPM. Engage the rotor and tub drive then throttle up to 1800 RPM. The FUSE light and the SENSOR light should come on. The tub should not be rotating at this time. If the tub is rotating, read section 6.1 “Troubleshooting the electronic governor system” in this manual.
5. Slowly rotate the ENGINE LOAD KNOB counterclockwise until the tub just begins to move. The tub should begin to rotate. If it does not begin to rotate, switch the range switch to M-Medium or L-Low and repeat as necessary.

TEST: Throttle the engine down and the tub should stop rotating, return the engine to 1800 RPM and the tub should start to rotate.

If the tub will not rotate, read section 6.1 “Troubleshooting the electronic governor system” in this manual.

3.12 Adjusting the tub's rotation speed

Tub rotation is controlled by two components . The tub is started, stopped and reversed by the tub forward/reverse control switch on the control panel, and the tub's rotation speed is controlled by the tub limit knob (tub speed knob) on the electronic governor.



3.13 Raising the tub



NOTE: If the grinder becomes plugged or if the rotor requires maintenance, do not raise the platform with the tub full of material.

To raise the tub, perform the following steps:

1. Verify that machine is parked on level ground.
2. Disengage the clutch, and wait for the rotor to stop turning.
3. If machine has a tub cover, close tub cover completely.
4. Remove the tub lock pin. See the next section for the location of the tub lock pin.
5. As material in the tub may roll some distance, make sure the area on the right hand side of machine is clear of personnel and equipment. Shout the word “CLEAR”.
6. The engine speed should be 1000 RPM.
7. Operate the tub tilt lever on the control panel to raise the tub. If the red tub interlock indicator on the control panel is lit, the tub will not raise. If the green tub interlock indicator on the operator station control panel is lit, the tub may be raised.
8. Raise the tub fully, and install the platform safety stop. The safety stop is located in its storage location under the platform.



platform safety stop




NOTE: The tub will not lift if the rotor is turning. Also, if the tub is raised and the clutch is engaged, the engine will shut off. **Never engage the clutch when the platform is raised.** The hydraulic cylinder will not raise the tub if the tub is full of material.



3.14 Lowering the tub

To lower the tub, perform the following steps:

1. Clear the area of equipment and personnel.
2. Engine speed should be 1000 RPM or less.
3. Remove the safety stop and place safety stop in storage location under the platform.
4. Operate the tub tilt switch on the control panel to lower the tub.
5. The tub lock pin must be reinserted after the tub platform is lowered fully. Verify that the tub lock pin is engaged before continuing.



tub lock pin in the locked position

3.15 Starting and stopping the discharge conveyor

The discharge conveyor is on one hydraulic circuit. The control is found at the control panel in front of the machine. The conveyor should be started before the rotor and should be allowed to run after the rotor is shut off.

3.16 Operating the grinder using the remote radio option

Using the Microtronics remote radio controller

Switch located on the control panel will switch from manual to remote control. Switch to remote when remote control is desired.

The remote will stop the engine, raise and lower the conveyor (if so equipped), and start, stop and reverse the tub. If your machine is equipped with a tub cover, the remote can also raise and lower the tub cover.

To stop the engine, push and hold the button until the engine stops. Starting the engine must be done at the control panel.

To change the conveyor height, push and hold the correct button (raise or lower) until the conveyor is at the desired height. Release the button.

To change tub cover height, push and hold the correct button (Opt1 or Opt2) until the tub cover is at the desired height. Release the button.

To change tub direction:

- If the tub is rotating forward, pushing the reverse button once will stop the tub. Pushing the reverse button the second time will reverse the tub. There is a two second delay when changing tub direction.
- If the tub is rotating in reverse, pushing the forward button once will stop the tub. Pushing the forward button the second time will start the tub rotating in the forward direction.



Using the Omnex Origa remote radio transmitter


The Remote/Local switch located on the control panel will switch from manual to remote control. Switch to remote when remote control is desired.

The transmitter will stop the engine, raise and lower the conveyor (if so equipped), and start, stop and reverse the tub. If your machine is equipped with a tub cover, the remote can also raise and lower the tub cover.

LED indicators

The yellow LED indicator is located on the upper right hand side of the radio transmitter. This LED indicates that the controller is powered up and transmitting. Light may be solid or flashing depending on mode. During normal operation this LED is flashing.

The red LED indicator is located on the upper left hand side of the radio transmitter. This LED flashes slowly to indicate the transmitter has less than twenty percent of battery capacity remaining.



When both the red and yellow LEDs are on, the transmitter is in configuration/program mode.

Mode of operation

The Omnex Origa system has several modes of operation. The mode preset for DuraTech Industries is:

1. The Power ON (green) button powers up the transmitter. Output 9 is energized when the Power ON button is pressed
2. All functions are shut off when the Power OFF button (red button) is pressed. When the radio is restarted, all functions will be off. The transmitter will stay on until the Power OFF button is pressed.

NOTE: The engine will also be shut off when the Power OFF button is pressed and the remote/local switch is set on radio.

3. Output 10 is energized when any of functions 3-8 are pressed.
4. Functions 1 & 2 are interlocked latched functions and are used for tub rotation. Pressing one function will start that function. It will not stop until either button is pressed. There is a two second delay when changing tub direction.
5. Functions 3-8 are interlocked momentary functions. These are used for hydraulic cylinder functions. These functions are energized only when the buttons are pressed.

For more information on using and troubleshooting the Omnex Origa system, please refer to Section 6.4, “Troubleshooting the Omnex Wireless Remote Controls which starts on page 74.



Remote radio start up

To begin using the remote radio, perform the following steps:

1. Press the green (power on) button on the transmitter. The yellow LED should start flashing to indicate that the transmitter is transmitting.
2. Set tub rotation to neutral on the machine's control panel.
3. Press the Radio start switch on the control panel and hold it in.
4. Set the radio switch on the control panel to remote.
5. Count to 5 and release the Radio start switch.



3.17 Grinding

Before you begin grinding, start the machine and check the direction of the tub's rotation. Also check the electronic governor for proper operation.

Watch for unusual or excessive vibration. If any occur, immediately shut off the power. Determine the cause and correct it before starting the grinder again.

In cold weather, warm up the machine for five minutes before grinding.

To begin grinding, perform the following steps:

1. Start the engine as described in "Starting the Industrial Grinder."
2. Unfold the discharge conveyor.
3. Push the conveyor run switch to the forward position.
4. If equipped with a tub cover, set tub cover to desired position.
5. Engage the rotor clutch.



IMPORTANT: Do Not engage clutch at high engine RPM. Before starting the engine, clear the rotor box of all material. Start the engine and set the engine speed below 1000 RPM. Engage the clutch **quickly** and **smoothly**. Bumping the clutch may release the torque limiter. Run grinder with no load for a few minutes to allow clutch plates to cool off. Any slippage during start-up heats the clutch plates. Check periodically for proper adjustment according to the specification plate on the clutch housing.

3.18 Loading the tub



IMPORTANT: Never drop a large object or objects into the tub from a high level. Ease the material over the edge and down into the tub carefully.

Material to be ground should be placed directly into the tub by approaching from the rear. The best method for filling the tub is:

1. Engage the rotor as described above.
2. Fill the tub about halfway full of unground material before starting tub rotation.
3. Start tub in the forward direction by switching on the electronic governor switch and engaging the tub control switch.
4. Place additional materials in the tub as needed.



3.19 If lodging occurs while grinding

Materials may lodge against the side of the tub and not feed down to the rotor. If this occurs, reverse the tub direction for part of a rotation and then start the tub in a forward direction again. This practice normally dislodges any materials.



CAUTION: Never attempt to dislodge material inside the tub when machine is in operation by manually pushing materials down. **TO PREVENT SERIOUS INJURY OR DEATH, STAY OUT OF THE TUB WHEN THE MACHINE IS IN OPERATION!**


3.20 Grinding wet material

Wet material is the toughest material for any grinder to handle. If possible, try to mix the wet materials with drier materials before grinding. When grinding wet material, deposit small quantities on a more frequent basis rather than filling the tub with wet material.

3.21 Preparing the HD-8 for transport

To prepare the HD-8 for transport over public roads, perform the following steps:

1. Be sure all loose parts such as screens, hammer rods, or extra hammers are properly stowed.
2. Rotate the tub so the flat flare lines up with the conveyor side of the machine. This allows the conveyor to fold up completely.
3. Raise and fold the discharge conveyor into the transport position which is shown in the figure below. When folding the conveyor, do not exceed an engine speed of 1000 RPM. Be certain that no power lines, branches, roof trusses, etc. will obstruct the folding operation of the conveyor.
4. Lock the conveyor in the transport position as shown in the photograph.
5. Close tub cover.
6. Shut down the engine using the normal shutdown procedure.



CAUTION: DO NOT MOVE INDUSTRIAL TUB GRINDER without first securing the conveyor in transport position with the conveyor lock pins as shown in the photograph.



7. Verify that the towing vehicle is properly coupled to the grinder hitch, and that the trailer wiring harness is properly connected to the towing vehicle.
8. Raise the trailer jack and lock the handle in its storage position.
9. Check the lights and the brakes for proper function.
10. Check the turning clearance between the grinder and the towing vehicle.
11. Check local ordinances regarding restrictions for machine travel on local roads.

Read the towing portion of the “Safety” section in this manual.

3.22 Preparing the HD-8 for operation after transport

To prepare the HD-8 for operation after transport, perform the following steps:

1. Check the location.
 - Are there power lines, branches, roof trusses, etc. that will obstruct the unfolding operation of the conveyor and the loading operation of the tub?
 - Position grinder to minimize the risk of thrown objects. For more information see section 1.6 on page 11.
2. Lower the trailer jack.
3. Disconnect the wiring harness from the towing vehicle.
4. Disconnect the towing vehicle from the grinder’s hitch.
5. Perform pre-operation inspection of the Industrial Grinder.
6. Start the engine.
7. Unlock the conveyor’s hydraulic cylinder by removing the lower lock pin.
8. Unfold the top section of the discharge conveyor until it is fully extended. When unfolding the conveyor, do not exceed an engine speed of 1000 RPM.
9. If equipped with tub cover, set tub cover to desired position.



3.23 Preparing the HD-8 for storage

To prepare the HD-8 for storage, perform the following steps:

1. The grinder tub has 4 pressure rollers with tapered roller bearings. These bearings should be checked for adequate lubrication and adjustment annually.
2. Change the hydraulic oil and filter every 500 hours of operation.
3. To prevent rust and make inspection easier, thoroughly clean the machine.
4. Check for loose or worn chains belts, sprockets and pulleys.
5. Check the condition of bearings.
6. Make sure that the batteries are fully charged before storing the unit.
7. Change the engine oil.

3.24 Removing the HD-8 from storage

To remove the HD-8 from storage, perform the following steps:

1. Perform a thorough pre-operation inspection.




3.25 Installing a screen



CAUTION: Follow normal shutdown procedure after tilting the tub and prior to performing any service work in the rotor area. Disengage the PTO, raise the platform, insert the safety stop, shut off the engine and remove the key before servicing the rotor.

To install a screen, perform the following steps:

1. Raise the tub completely, install the tub platform safety stop, and remove engine key.
2. Unbolt and remove screen hold downs.
3. Screens may be lifted from or placed in the machine with a hoist or lifting device.
4. Securely attach the screen to the lifting device with a sturdy chain or nylon sling. Screens can weigh over 500 lb. each, but screens which are stuck can require a force many times their weight to lift them free of the grinder.
5. Use only pry bars to guide the screens in and out of the machine. The screens are very heavy and could easily cause injury if the screen moves suddenly or is inadvertently dropped.
6. Clear all material from the screen track before installing a new screen.
7. Install the new screen using the lifting device and pry bars as explained above.



IMPORTANT: Make certain screen fits completely in place before proceeding to step 8.

8. Return the screen hold downs to their position over the screens and install and tighten the bolts.
9. Make sure all personnel and equipment are clear of the tub platform.
10. Remove the safety stop and lower the platform.




3.26 Adjusting the conveyor belt tension

The discharge conveyor is adjustable to allow for belt stretch and tracking. If the conveyor belt slows down or stops during operation, slippage may be the cause. To eliminate slippage, tighten the adjusting bolts on the conveyor equally. This will increase the conveyor belt's tension and help to keep the belt centered on the rollers.




IMPORTANT: Do not overtighten conveyor belts. Use only enough tension to eliminate belt slippage.

figure 3.3
discharge conveyor belt
adjusting bolts



discharge conveyor
belt adjustment bolt
(one on each side
of the discharge
conveyor)

figure 3.4
idler roller tension bolt



idler roller tension bolt



3.27 Adjusting the conveyor belt tracking

A. When a new belt is installed, use only genuine DuraTech Industries parts.

1. Begin by adjusting the drive roller so that the mounting bearings are the same distance from the end of the conveyor frame. This ensures that the roller centerline is square with conveyor frame. Adjust the idler roller bolts so that they are equal on both sides of the conveyor.

B. If the belt is running to the right side, perform the following steps:

1. Adjust the idler roller tension bolt on the right side of the conveyor (figure 3.4). Decrease tension by approximately 1/2 turn of the adjusting nut.
2. Make certain that all personnel are clear of machine and the start engine. Engage the hydraulic conveyor drive switch.
3. Observe conveyor belt tracking from a safe location.
4. If further adjustment is required, disengage hydraulic conveyor drive switch and shut down the machine using the normal shutdown procedure.
5. Some adjustment of the drive roller may be required if no improvement is noted by adjusting the idler roller tension.
6. Repeat steps 1-5 until proper tracking is achieved.

C. If the belt is running to the left side, perform the following steps:

1. Adjust the idler roller tension bolt on the right side of the conveyor. Increase the tension by approximately 1/2 turn of the adjusting nut.
2. Make certain that all personnel are clear of machine and start engine. Engage the hydraulic conveyor drive switch.
3. Observe the tracking of the conveyor belt from a safe location.
4. If further adjustment is required, disengage hydraulic conveyor drive switch and shutdown using the normal shutdown procedure.
5. Some adjustment of the drive roller may be required if no improvement is noted by adjusting the idler roller tension.
6. Repeat steps 1-5 until proper tracking is achieved.




3.28 Sizing the tub drive chain

Tub drive chain is equipped with a spring tensioned frame which take up the slack in the chain during normal operation. Due to normal wear the tub drive chain may tend to climb on driving teeth of the tub. If this should occur, the chain should be sized to fit the tub, and the tub teeth adjusted for proper spacing in the chain.

To size the tub drive chain, perform the following steps:

1. Remove the tub drive chain from the drive sprocket. Loosen the tub teeth and wrap the chain around tub, but do not run the chain around drive sprocket. Using a 1/2" bolt inserted through the chain links, draw the chain together so that the center to center measurement on link pins matches the pins on the connector link. If the distance is less than or greater than the connector link, shims must be added. Equally space shims of the same thickness and length under the chain until the proper distance is obtained. Do not add shims under the tub teeth.
2. Adjust the tub teeth so that all four sets of teeth contact the chain link on the same side of the teeth. Tighten the bolts holding the teeth in place, and return the chain to working position.



3.29 Adjusting tub chain tension

To adjust the tub chain tension, perform the following steps:

1. Position tub so teeth are oriented as shown.
2. Adjust bracket - spring engagement to 1/4" to 3/8" using Nut A. See illustration on facing page.
3. Tighten Nut B.



figure 3.5
adjusting tub
chain tension





figure3.6
adjusting tub
chain tension
illustration





figure 3.13
tub tension bracket





3.30 Ball type torque limiter


The ball type torque limiter used on the HD-8 Series V can best be described as a resettable shear pin. The torque limiter is set high enough to minimize nuisance releases but low enough to protect the driveline and rotor from damage due to excessive loads. Bumping the clutch when engaging the rotor with this type of torque limiter can cause nuisance releases also.

The clutch should be engaged smoothly and quickly to avoid releasing the torque limiter and minimize heating in the clutch plates. Engage the clutch as you would engage the clutch in a heavy truck when starting from a dead stop.

When the torque limiter releases due to an overload, proceed with the following steps:

1. Throttle the engine to idle speed and release the clutch.
2. Unpin and raise the tub platform. Insert the platform safety stop.
3. Shut the engine down and remove the key.
4. Remove material that caused torque limiter to release.
5. Identify and align the index marks on the torque limiter.
6. Engage the safety element pins by tapping on them with a soft face mallet or a wood block.
7. Store the platform safety stop, lower the platform, and install the lock pin.
8. Start the rotor by engaging the clutch smoothly and quickly.
9. Throttle the engine to operating speed and resume grinding.

figure 3.7
ball type torque limiter






3.31 Checking for wear on the friction disc torque limiter

The friction disc torque limiter a unique, maintenance free, friction type, overload friction disc torque limiter which offers precise torque control.

This friction disc torque limiter requires no routine maintenance, and it can be allowed to wear until the wear indicator becomes flush with the face surface “X” of the pressure plate.

The wear indicator should be checked as required by the application. The output hub should be rebuilt or replaced when the clutch is deemed to be worn out. If the friction disc torque limiter continues to wear and the wear indicator protrudes, then the friction disc torque limiter’s torque capacity may drop rapidly.



WARNING: The spring bolts contain heavy springs which are highly compressed . They should not be tampered with. **DO NOT** attempt to disassemble the spring bolts. If a spring bolt is damaged, dispose of it in a safe manner.



wear indicator



3.32 Engaging and adjusting the rotor clutch



IMPORTANT: Read and have a thorough understanding of the clutch's operators manual and the specification plate found on the clutch's housing.




IMPORTANT: Do Not engage the clutch at high engine RPM.

To engage the clutch, perform the following steps:

1. Before starting engine, the rotor box should be cleared of all material.
2. Start the engine and set the engine speed to below 1000 RPM.
3. The clutch should be engaged smoothly and quickly to avoid releasing the torque limiter and minimize heating in the clutch plates. Engage the clutch as you would engage the clutch in a heavy truck when starting from a dead stop.
4. Run grinder with no load for a few minutes to allow clutch plates to cool off.
5. Check periodically for proper adjustment according to the specifications plate on clutch's housing.

figure 3.8
clutch adjustment



DAMAGE DUE TO EXCESSIVE SLIPPING WILL NOT BE COVERED BY THE WARRANTY.

A new clutch generally requires several adjustments until friction surfaces are worn in. Do not let a clutch slip as this will glaze the friction plates and may ruin them. A new power take off should have its clutch adjustment frequently during the first ten (10) hours of service.



If force required to engage clutch drops below 80 pounds, the clutch slips, overheats, or the clutch operating lever jumps out, the clutch must be adjusted.

To adjust the clutch, perform the following steps:

1. Use the normal shutdown procedure to shut down the engine before performing any clutch adjustments.



CAUTION: If the clutch has been allowed to slip, the clutch components can be very hot. Allow parts to cool before performing any adjustments.


2. Remove the hand hole plate from the housing, and rotate the clutch until the adjusting lock pin can be reached.
3. Disengage the adjusting lock pin and turn the adjusting ring until the operating shaft requires the amount of torque listed in figure 3.8. The amount of torque should be the higher value listed for your clutch model's torque range. See figure 3.8 for information about your clutch model.
4. Perform this adjustment again when the torque value drops below the smaller value listed in the same table.

3.33 Electro-hydraulic valve coil test

See the figure 3.9 for the location of the electro-hydraulic valve coil.

This test requires an accurate ohm meter. Disconnect the wiring harness leads at the electro-hydraulic valve coil. Check resistance of valve coil leads at the terminals. The resistance should be between 8 to 12 ohms. If the values are not within this range, replace the electro-hydraulic valve coil.

figure 3.9
electronic governor
system





MANUAL OVERRIDE

NOTE: If there is an electrical failure with the machine, it may still be able to grind.

To grind using manual override, perform the following steps:

1. Switch the electronic governor off.
2. To access the electro-hydraulic valve, Start the engine, raise the platform, and install the platform safety stop. The procedure for raising the tub can be found in section 3.13 on page 31 of this manual.
3. Remove the rubber end cap and loosen the jam nut on the electro-hydraulic valve.
4. Engage the tub drive.



IMPORTANT! - DO NOT ENGAGE THE ROTOR CLUTCH AT THIS TIME!

5. Turn the adjusting stud clockwise until the tub rotates at the desired speed.
6. Lock the jam nut on the adjusting stud and replace the rubber end cap on the electro-hydraulic valve.
7. Remove the platform safety stop and lower the platform. The procedure for lowering the tub can be found in section 3.14 on page 32 of this manual.

When the electro-hydraulic valve is adjusted in this manner, it will function only as a manual flow control. The grinder will now operate as it would if the electronic governor were switched to the tub (manual) mode. The tub speed will be constant and it will not change to match varying load conditions.

Contact your dealer for repair or replacement parts. When the problems are corrected, calibrate the electro-hydraulic valve.




3.34 Electro-hydraulic valve calibration



IMPORTANT: Stay clear of all moving parts while calibrating the electro-hydraulic valve. **The tub will be rotating during this adjustment.**

figure 3.10
electro-hydraulic valve



To calibrate the electro-hydraulic valve coil perform the following steps:

1. To access the electro-hydraulic valve, Start the engine, raise the platform, and install the platform safety stop. The procedure for raising the tub can be found in section 3.13 on page 31 of this manual.
2. Remove the rubber end cap from the end of the electro-hydraulic valve. This will reveal a jam nut and an adjusting stud with a screwdriver slot.
3. Disconnect the wiring harness from the electro-hydraulic valve coil, and loosen the jam nut.
4. Engage the tub drive in the forward direction. Throttle the engine up to a fast idle.



IMPORTANT! - DO NOT ENGAGE THE ROTOR CLUTCH!

5. If the tub is not rotating, turn the adjusting screw clockwise until it bottoms out. Turn the adjusting screw counterclockwise until the tub stops. The electro-hydraulic valve is now calibrated.
6. Lock the adjusting screw with the jam nut and replace the rubber cap. Shut down the machine using the normal shutdown procedure in this manual. Reconnect the wiring harness to the electro-hydraulic valve coil.



Section 4: Engine Maintenance

Engine oil level, engine coolant level, air filters, and fan belt tension should be checked daily. Follow the engine manufacturer's recommendations for the replacement of parts and fluids, and follow the manufacturer's recommended maintenance schedule. Engine specifications should be found in the Operation and Maintenance manual for the engine.



WARNING: All debris, wood chips, and combustible or ignitable material should be cleared from the engine compartment daily or more often as conditions warrant. When cleaning the engine compartment, pay particular attention to the top of the engine.

Section 5: General Maintenance



WARNING: Before servicing machine, read the Service and Maintenance section of the Safety Instructions.



IMPORTANT: If for any reason arc welding is to be done, always ground rotor to frame of machine to prevent arcing in bearings.

5.1 Welding Procedure

Precautions are required for welding on machines with electronic components. Electronic components including but not limited to: radio receiver, electronic governor, and ABS controllers.

Proper welding procedures are necessary in order to avoid damage to the components, their sensors, and associated components.

If at all possible, the part that is to be welded should be removed from the machine for welding.

If removal of the part is not possible, the following procedure must be followed when welding on a machine that is equipped with electronic components. This procedure is considered the safest and should provide minimum risk of electronic component damage.



NOTE: Do not ground the welder to electrical components listed above, sensors, or wiring. Improper grounding can also damage bearings or hydraulic components. Clamp the ground cable from the welder to the part that will be welded. Place the clamp as close as possible to the weld. This will help reduce the possibility of damage.

1. Stop the engine. Turn the switched power to the OFF position. Tag the machine out for repairs.
2. Disconnect the negative battery cable from the battery.



IMPORTANT: Components with electric circuit boards must be disconnected before welding to prevent accidental electrical damage to the boards. These components include **radio controllers and the electronic governor.**

3. Disconnect the connectors from the equipment listed above. Move the connectors to a position that will not allow the connectors to accidentally move back and make contact with any of the pins.
4. Connect the welding ground cable directly to the part that will be welded. Place the ground cable as close as possible to the weld in order to reduce the possibility of welding current damage to the bearings, hydraulic components, and electrical components.



NOTE: If the electrical/electronic components are used as a ground for the welder, or electrical/electronic components are located between the welder ground and the weld, current flow from the welder could damage the components.

5. Protect the wiring harness and oil lines from welding debris and spatter.
6. Use standard techniques to weld the materials.



5.2 Batteries

Check the condition of the batteries to insure that the electrolyte level is correct. Make sure that the terminals and cables are not corroded, and that the battery is held in place properly. Also make sure there is no arcing or grounding by the terminals.

The system uses one 12 volt battery.



CAUTION: Hydrogen gas given off by a battery is explosive. Keep sparks and flames away from the battery. Before connecting or disconnecting a battery charger, turn the charger off. Make last connection and first disconnection at a point away from the battery. Always connect the NEGATIVE(-) cable last and disconnect the NEGATIVE(-) cable first.

5.3 Lubrication



CAUTION: Always shut off machine before adjusting or lubricating. When grinder is operated during cold weather, all lubrication should be performed after bearings are at operating temperatures.

Since a full bearing with a slight leakage is the best protection against entrance of foreign material, bearings operating in the presence of dust and water should contain as much grease as speed will permit. At higher speed ranges, too much grease will cause the bearings to temporarily overheat.

Abnormal bearing temperature during high speed operation may indicate faulty lubrication. The normal temperature may range from cool to warm to the touch. If a bearing is too hot to touch for more than a few seconds and the bearing is leaking grease excessively, there is too much grease in the bearing. High bearing temperatures with no grease showing at the seals, particularly if the bearing seems noisy, usually indicates too little grease. Normal temperature and slight showing of grease at the seals indicate proper lubrication.

The Lubrication Chart is a general guide for “relubrication”. Certain conditions may require a change of lubrication periods as dictated by experience.

A heavy-duty, general-purpose, lithium-based grease is recommended for lubricating the HD-8 Industrial Tub Grinder unless otherwise noted.




chart 1
lubrication chart

Ref. No.	Location	No. of Zerks	Frequency
1	Wheel Bearing	Check Oil Level	Daily/per Trip
2	Roller Chains	Graphite Spray	Daily
3	Rotor Bearing, grease	2	Daily
4	Drive Line	5	40 Hours
5	Tub Drive Shaft	2	40 Hours
6	Tub Pivot, 50 deg tub tilt	2	40 Hours
7	Discharge Conveyor Rollers	4	40 Hours
8	Optional Tub Cover Pivot Points	4	40 Hours
9	Clutch Operating Shaft	2	100 Hours
10	Clutch Throw Out Collar	1	100 Hours
11	Clutch Main Bearing	1	100 Hours
12	Control Panel Pivot	1	100 Hours
13	Tub Drive Orbit Motor Pivots	1	1000 Hours
14	Clutch Lever Jack Shaft	2	1000 Hours
15	Tub Pressure Roller	Inspect and Repack	1000 Hours
16	Ball Detent Torque Limiter S.N. II0359 to AJ420	2	Quarterly, light grease, Mobile XTC
17	Ball Detent Torque Limiter Safety Element S.N. II0359 to AJ420	2	Quarterly, light grease, Mobile XTC
18	Main Clutch Bearing	Inspect and Repack	4000 Hours



figure 5.1
roller chain and
tub drive shaft
lubrication points




tub drive shaft
lubrication zerk
(ref 5)

roller chains (ref 2)

tub drive orbit motor
pivot lubrication
zerk (ref 13)

tub drive shaft
lubrication zerk
(ref 5)

figure 5.2
operating shaft-
clutch, main
clutch bearings,
throw out collar-
clutch lubrication
points



lubrication
zerks

clutch main
bearing
(ref 11)

clutch throw
out collar
(ref 10)

clutch
operating
shaft (ref 9)

main clutch bearing - must
also be inspected and
repacked every 4000 hours
(ref 18)



figure 5.3
 optional tub cover lubrication
 points (left), tub tilt pivot
 point lubrication (right)




optional tub cover
 pivot lubrication
 zerks (ref 8)

tub pivot, 50 deg. tub tilt -
 lubrication zerks (ref 6)



figure 5.4
 clutch lever jack shaft (left),
 rotor bearing lubrication
 zerk (right)



clutch lever jack shaft
 lubrication zerk (ref 14)



rotor bearing lubrication zerk
 (ref 3)



figure 5.5
upper and lower
discharge conveyor
roller lubrication zerks
and rotor bearing
lubrication zerk




figure 5.6
control panel pivot
lubrication zerk







figure 5.7
drive line lubrication
points and torque
limiter



ball detent torque limiter
safety element
(2-3 pumps of Mobil XTC
quarterly) (ref 17)

ball detent torque limiter
bearing zerks (4-5
pumps of Mobil XTC
quarterly) (ref 16)

drive line zerks
(ref 4)

5.4 Pressure roller lubrication

The grinder has four pressure rollers with tapered roller bearings. These bearings should be checked for adequate lubrication and adjustment every 1000 hours of operation or annually, whichever comes first.



tub pressure roller (ref 15)
(behind access panels)



5.5 Hydraulic system



CAUTION: Lack of proper hydraulic oil level in the reservoir tank will cause system to heat under continuous running. Check the hydraulic oil level daily and replace as necessary.

The hydraulic oil filter should be changed after the first 10 hours and 100 hours of operation. Thereafter, change hydraulic oil filter every 500 hours and change hydraulic oil and filter at least every 1000 hours of operation.

Check the hydraulic oil regularly, and if the oil has a burnt smell or milky appearance, change it immediately.

When adding or replacing hydraulic oil, use Mobil 423, Farmland Super HTB or another similar hydraulic oil.

DuraTech Industries recommends using Conoco Hydroclear Power Tran Fluid if your machine has a Hydroclear decal on the hydraulic tank. Other acceptable fluids include Mobil 423, Farmland Super HTB, or other similar fluids. If the hydraulic tank does not have this decal, then all of the above fluids are acceptable.




figure 5.8
hydraulic system oil
filter



hydraulic oil
filter

figure 5.9
hydraulic oil level
dipstick



dipstick



5.6 Axle, wheels and tires

TIRE PRESSURE

Set the tire pressure according to the manufacturer's specifications. The appropriate tire pressure can be found on the sidewall of the tire.

WHEEL BEARINGS

The wheels have tapered roller bearings in an oil bath. Each hub is equipped with a transparent oil cap which has an oil level indicator mark that allows for easy checking of the oil level. The oil level should be checked daily during the pre-operation inspection. This lubrication method assures long bearing life with proper maintenance of the oil level.

When adding or replacing oil in the wheel bearings, use SAE 80W-90 HYPOID GEAR OIL.



oil fill cap (ref 1)



5.7 Hammermill maintenance

Visually examine the mill to see if any of the internal parts show excessive wear. These parts should include liners, rotor discs and the holes in the discs that support the rods. Enlarged holes can cause rods to break or bend. Also check rods, rod locking or retaining devices, hammers, screens, screen tracks and hold downs, main shaft, platform locking devices, hinges or anything else that could wear and perhaps fail and causing damage to the hammermill and/or personnel if not properly maintained. The bearings and rotor alignment should also be checked along with mounting bolts to insure a firm foundation and reduced vibration.



CAUTION: Keep all foreign objects out of the tub and away from the mill. Foreign objects may result in personal injury or damage to the machine.

The hammers are designed to grind products such as wood waste, chips, sawdust, shavings, or hogged materials that may be reduced in size in a hammermill. The hammers are not designed to grind or crush hard materials such as coal, minerals, metals, rock, or other incompressibles, which could cause parts to fail. These materials should never be allowed to enter a hammermill.

The hammers have been designed and manufactured to provide the best compromise between hardness for good wearing qualities and strength for dependability and resistance to breakage.



WARNING: The hammers have been heat treated, and any alteration of the hammers by heating, grinding, resurfacing or any other process can change the mechanical properties of the hammer and make it unsuitable or dangerous to use.

Because of the high capacity of the machine, the hammers will wear and must be considered expendable. Each hammer has two cutting edges. For maximum life, it is suggested that hammers be rotated periodically to even out the wear over the entire rotor. If one corner of a hammer is allowed to wear too long, one of the hammer's cutting edges will be lost.

Screens also have two cutting edges. When cutting edges become rounded, the screen can be turned end for end exposing the new cutting edges. The results of badly worn hammers and screens is loss of capacity, and added horse power requirements.

Hammer rods are case hardened to maximize wearability and toughness, however hammer rods must be considered expendable.



NOTE: Hammer and hammer rod life can be extended by keeping rotor rotating at 2000 RPM. Over powering or over feeding the rotor will cause the swinging hammers to lay back resulting in excessive wear on both hammers and hammer rods.



5.8 Fixed hammer maintenance and replacement



CAUTION: Disengage the driveline clutch. Shut off the engine. Remove the key before working on the rotor.



IMPORTANT: The bolts on the hammer tips should be checked periodically for proper torque. Torque ratings for two bolt tips are given in the hammer tip replacement procedure in this section.

When replacing hammer tips, We recommend the following:

- A. Always replace fixed hammer tips in pairs, 180 degrees apart (same as with the swinging hammers, illustrations A & B figure 5.10).
- B. Tips placed 180 degrees apart should be the same weight.
- C. When starting the hammermill after installing a new set of tips or after turning the tips to expose new faces, watch for unusual or excessive vibration. If any is noticed, shut off the hammermill. Determine the cause and correct it before starting the mill again.

To replace the hammer tips on machines with fixed hammers, perform the following steps:

1. Be sure to disengage the clutch, wait for rotation to stop, raise the platform and install safety stops, shut down the engine, and remove the key.
2. Identify the tips to be removed, then loosen and remove the bolts and tips.
3. Rotate or replace tips. Use new bolts and lock nuts when replacing tips.



4. **FIXED HAMMER TORQUE SPECIFICATIONS** For two-bolt tips with 5/8" NF grade 8 bolts and grade 8 lock nut, Torque to 190-210 ft.lbs.

5. After 2 hours of grinding, retighten the bolts to the same torque values.
6. Periodically retighten the bolts to the same torque values.



5.9 Swinging hammer replacement and maintenance



CAUTION: Disengage the PTO, shut off the engine and remove the key before working on the tub.

When installing or changing hammers, be sure to follow the hammer diagram carefully. Misplacement of the hammers could cause excessive vibration. We recommend that hammers be balanced in sets according to the rod on which they are to be installed. Sets of equal weight should be installed 180 degrees apart (See Illustration A). When replacing a worn or broken hammer with a new hammer always install a second new hammer 180° away from the first (see Illustration B). When starting the hammermill after installing a new set of hammers or turning corners, watch for unusual or excessive vibration. If any occurs, immediately shut off the mill. Determine the cause and correct it before starting the mill again.

To replace worn hammers on machines with swinging hammers, perform the following steps:

1. Follow the normal shutdown procedure which can be found on page 25 of this manual.
2. Loosen the bolts at both ends of the rotor which hold the hammer rod retainer plates in place.
3. Rotate the retainer plates to align holes allowing the hammer rods to be removed through either end of rotor.
4. Remove one row of hammers and replace individual hammers as necessary. Note the location of any spacers. See hammer spacing charts.
5. After all the hammers have been replaced, rotate the retainer plate to lock hammer rods in place, and tighten the eight retainer plate bolts.



IMPORTANT: Care should be exercised when replacing only a few hammers and not the entire set. If one or more new hammers are inserted on a rod, the same number of new hammers should be inserted on the rod directly across the rotor. This will maintain a balanced rotor for vibration free operation.

figure 5.10
hammer
replacement
illustrations A + B






figure 5.11
full set swinging
hammer spacing




figure 5.12
1/2 set swinging
hammer







figure 5.13
fixed hammer pattern





Section 6: Troubleshooting the HD-8

6.1 Troubleshooting the electronic governor system

1. When power is reaching the electronic governor the fuse light should be on. If this light fails to go on, check the fuse, the battery connections, the wiring harness, and the indicator lamp. If the fuse light is on, the wiring harness, battery connections, fuse and bulb are functioning correctly.
2. Verify that there are good ground connections.
3. Checking the TUB MODE operation of the electronic governor. With the engine and hydraulic systems at operating temperature, and the tub drive control switch in the forward position, throttle the engine up to 1800-2000 RPM.

With the mode switch in the tub position, the tub should be rotating. The speed of the tub can be varied by rotating the tub limit knob. The number of tub speed lights which are lit will vary with the setting of the tub limit knob. If the number of tub speed lights lit varies as you rotate the tub limit knob and the tub speed varies accordingly, the manual portion of the controls are functioning correctly. Proceed to step 3. If the manual portion is not working properly, proceed to trouble shooting table 6.1.

Table 6.1 Troubleshooting the electronic governor's engine mode

PROBLEM	CAUSE	REMEDY
1. The tub does not rotate but the electronic governor and the manual hydraulic valve are working properly. There is pressure to the orbit motor.	<ol style="list-style-type: none"> 1. The tub is binding. 2. There is too much material in tub, or the tub is overloaded due to wet or tough grinding material. 3. The pressure relief valve in the control valve set too low or is faulty. 	<ol style="list-style-type: none"> 1. Remove the material causing problem. 2. Reduce the amount of material in the tub. 3. Check oil pressure
2. The tub does not rotate, but the valve is receiving 9 to 12 volts of DC power. There is no pressure to the orbit motor. Note: The valve refers to the valve where you disconnect the wiring harness. For more information see "Electronic governor hardware test" later in this section.	<ol style="list-style-type: none"> 1. The manual hydraulic valve is not engaged. 2. The valve assembly is dirty or faulty. 3. The solenoid is faulty. 	<ol style="list-style-type: none"> 1. Engage the manual hydraulic valve. 2. Clean or replace the valve assembly. 3. Test the solenoid and replace as necessary.
3. The tub does not rotate, and there is no voltage to the valve.	<ol style="list-style-type: none"> 1. There is no power to the electronic governor. <ol style="list-style-type: none"> a The electronic governor is switched off. b The fuse is blown. c The tub limit knob is set fully counterclockwise. 2. A wire in the wiring harness is broken. 3. The electronic governor is faulty. 	<ol style="list-style-type: none"> 1. a Switch the electronic governor mode switch to tub. <ol style="list-style-type: none"> b Replace the fuse. c Turn the tub speed knob clockwise. 2. Replace or repair the wiring harness. 3. Replace the electronic governor.
4. The tub runs with the electronic governor switch off. Disconnect the wiring harness at the valve. A. If the tub stops B. If the tub keeps turning	<ol style="list-style-type: none"> 1A. The electronic governor is out of adjustment. 2A The electronic governor is faulty. 1B. The valve override screw is adjusted in too far. 2B The valve is faulty. 	<ol style="list-style-type: none"> 1.A Readjust the electronic governor. 2.A Replace electronic governor. 1.B Adjust the override screw. 2.B Replace the valve.
5. The tub speed can not be varied with the tub limit knob.	<ol style="list-style-type: none"> 1. Valve override is not adjusted correctly. 2. The valve is stuck. 3. The solenoid is stuck. 4. The electronic governor is faulty. 	<ol style="list-style-type: none"> 1. Adjust the override screw. 2. Clean or replace the valve assembly. 3. Test the solenoid and replace as necessary. 4. Replace the electronic governor.



4. Checking the ENGINE MODE operation of the electronic governor. If the tub mode controls function correctly after following the tub mode trouble shooting check list, then follow the calibration instructions on page 30 of this manual. If the tub will not rotate, proceed to trouble shooting table 6.2.

Table 6.2 Troubleshooting the electronic governor's engine mode

PROBLEM	CAUSE	REMEDY
1. The tub will not rotate, and the sensor light is not lit.	<ol style="list-style-type: none">1. The sensor gap is out of adjustment.2. There is a broken wire on the wiring harness.3. The sensor is faulty.4. The sensor light bulb is faulty.5. The electronic governor is faulty.	<ol style="list-style-type: none">1. Readjust the sensor gap to 3/32". This is roughly the thickness of a nickel.2. Repair or replace the wiring harness.3. Test and replace the sensor as necessary.4. Replace the sensor light bulb5. Replace the electronic governor.
2. The tub will not rotate, and the sensor light is lit.	<ol style="list-style-type: none">1. The tub limit knob is set fully counter-clockwise.2. The manual hydraulic valve is in the neutral position.3. The electronic governor is faulty.	<ol style="list-style-type: none">1 Adjust the tub limit knob clockwise.2 Engage the manual hydraulic valve.3. Replace the electronic governor.




ELECTRONIC GOVERNOR HARDWARE TEST



NOTE: HD-8 Series V utilizes 12 volt systems.

1. Power source: 12 volts DC
 Red wire + positive pin A wiring harness
 Black wire - Negative Pin B wiring harness
2. Test output voltage to valve DC
 Red wire + positive pin D wiring harness.
 Black wire - negative pin E. wiring harness.

electronic governor
wiring harness



- A - 12 volts DC ignition**
- B - Ground**
- C - Digital sensor signal***
- D - 0 to 12 volts (+) to valve**
- E - 0 (-) to valve**

Test the electronic governor with power supplied to the governor control box and the mode switch set to the tub position. The grinder does not need to be running for this test. Disconnect the wiring harness at the valve. With a voltmeter set for 12 volts DC, connect the red lead of the voltmeter to the red lead of the wiring harness and black lead to the black wire. Turn the tub limit knob until the left speed light (turtle) is on. The voltmeter should read approximately 3 volts. Turn the tub limit knob clockwise. As more speed lights light up, the voltage should increase. Turn the knob until the right speed light (Rabbit) is lit. The volt meter should now read a minimum of 9 volts.

3. Output voltage of sensor AC
 red wire - Pin C wiring harness
 Black wire - Pin B wiring harness.

Set the sensor gap to 3/32".

Remove the wiring harness from the electronic governor.

With the engine at operating temperature and the clutch engaged, throttle the engine up to 2000 engine RPM.



ELECTROHYDRAULIC VALVE COIL TEST

See the figure 6.1 for the location of the electro-hydraulic valve coil.

This test requires an accurate ohm meter. Disconnect the wiring harness leads at the electro-hydraulic valve coil. Check resistance of valve coil leads at the terminals. The resistance should be between 8 to 12 ohms. If the values are not within this range, replace the electro-hydraulic valve coil.

MANUAL OVERRIDE

NOTE: If there is an electrical failure with the machine, it may still be able to grind.

To grind using manual override, perform the following steps:


1. Switch the electronic governor off.
2. To access the electro-hydraulic valve, Start the engine, raise the platform, and install the platform safety stop. The procedure for raising the tub can be found in section 3.12 on page 31 of this manual.
3. Remove the rubber end cap and loosen the jam nut on the electro-hydraulic valve.
4. Engage the tub drive.



IMPORTANT! - DO NOT ENGAGE THE ROTOR CLUTCH AT THIS TIME!

5. Turn the adjusting stud clockwise until the tub rotates at the desired speed.
6. Lock the jam nut on the adjusting stud and replace the rubber end cap on the electro-hydraulic valve.
7. Remove the platform safety stop and lower the platform. The procedure for lowering the tub can be found in section 3.13 on page 32 of this manual.

figure 6.1
electronic governor
system





When the electro-hydraulic valve is adjusted in this manner, it will function only as a manual flow control. The grinder will now operate as it would if the electronic governor were switched to the tub (manual) mode. The tub speed will be constant and it will not change to match varying load conditions.

Contact your dealer for repair or replacement parts. When the problems are corrected, calibrate the electro-hydraulic valve.

6.2 General Troubleshooting

PROBLEM	CAUSE	REMEDY
1. No grinding capacity	<ol style="list-style-type: none"> 1. The screen is plugged. 2. The hammers or screens are badly worn. 3. Materials are too light or fluffy. 	<ol style="list-style-type: none"> 1. Clean out the holes in the screen. 2. Replace or turn worn parts. 3. Mix the lighter material with heavier material. 4. Use a larger screen. 5. Reduce length of input material to reduce bridging in tub.
2. The tub slows down or turns slowly.	<ol style="list-style-type: none"> 1. The electronic governor is not adjusted properly. 2. The electronic governor system malfunctions. 3. The hydraulic pressure is low. 	<ol style="list-style-type: none"> 1. See the sections on the electronic governor in the operations section of this manual. 2. See Troubleshooting the electronic governor in this manual. 3a. Check oil pressure. 3b. Look for internal leakage or wear in the orbit motor or pump.
3. The machine vibrates excessively.	<ol style="list-style-type: none"> 1. A hammer is broken. 2. The hammer pattern is incorrect. 3. The rotor bearing is defective. 4. The driveline is worn or misaligned. 5. Foreign material is wrapped in the rotor. 	<ol style="list-style-type: none"> 1. Replace the broken hammer. See page 48-54 for more information about replacing hammers. 2. See page 48-54 for more information about replacing hammers. 3. Replace the rotor bearing. 4. Replace worn part or the complete driveline. 5. Remove the foreign material.
4. The engine looses excessive RPM's before the tub stops.	<ol style="list-style-type: none"> 1. The electronic governor is not adjusted properly. 	<ol style="list-style-type: none"> 1. See the sections on the electronic governor in the operations section of this manual.
5. The tub stalls.	<ol style="list-style-type: none"> 1. The tub is overloaded due to wet or tough grinding materials. 2. Too much material in the tub. 3. The tub is binding. 4. The tub hydraulic system pressure is set too low. 5. The hydraulic oil is too hot causing electronic governor valve to bind. 	<ol style="list-style-type: none"> 1. Blend dry material with wet material. 2. Reduce the amount of material in tub. 3. Remove material buildup between the tub and the platform framework. 4a. Check oil pressure. 4b. Readjust the pressure relief valve to 1750 PSI max. 5. Reduce the load on the hydraulic system, or stop and allow the hydraulic oil to cool.
6. The hydraulic oil overheats.	<ol style="list-style-type: none"> 1. Pressure relief valve is faulty. 2. The tub is overloaded. 3. Worn pump, control valve, hyd. motors, etc. 	<ol style="list-style-type: none"> 1. Check oil pressure (1750 PSI). 2. Reduce the amount of material in the tub. 3. Rebuild or replace the hydraulic components as necessary.



6.3 Troubleshooting Microtronics wireless remote controls

Manual / Remote Switch

Check operation of the tub grinder with the manual / remote switch in the “manual” position before troubleshooting the wireless remote control system. If the grinder functions properly in “manual” position and will not function properly in the “remote” position then proceed with troubleshooting of the remote control system. If the grinder will not function in the “manual” position, the problem is not in the wireless remote system.

Transmitter Battery

The transmitter is powered by a 9 volt battery. Replace battery with alkaline 9-volt battery. Do not use rechargeable nicad or “Heavy Duty” rated batteries. Remove the battery cover on the lower back of transmitter housing. Plug the 9-volt battery to the battery clip and install inside the chassis. Replace battery cover and you are ready to use the transmitter.


To operate the transmitter, push any switch for desired operation. There is no battery drain on the transmitter when a button is not pushed. If transmitter is not to be used for long periods of time, remove the battery.

Receiver

The receiver is mounted in the control panel enclosure on the front end of the grinder. It is a white metal box with 4 screws on the cover. A manual / remote switch is located on the operations control panel on the front of the engine. Power is supplied to the receiver only when this switch is placed in the “remote” position.



figure 6.2
wireless remote
receiver circuit board



Receiver Power Check

Remove the cover to the receiver and locate the power indicator lamp (11). Place the manual / remote switch in the “remote” position and turn the engine keyswitch to the “run” position (do not start the engine!). The power indicator lamp (11) should come on. If it does not come on, check the 7.5 amp fuse found in the upper right hand corner of the receiver box. If the fuse is good, check for wiring continuity from the manual / remote switch to the radio receiver. 12 volts DC should be available at the power terminal inside the receiver enclosure.


Receiver / Transmitter Communication Check

If the power indicator lamp (11) is on, then proceed to test the remote functions. Begin by pressing and holding the ENG button on the transmitter. The RF indicator lamp (10) should come on. When the RF indicator lamp (10) comes on, that is proof that the transmitter is sending a signal and the receiver is receiving the signal. This is true for any of the functions available on the transmitter. If the RF indicator lamp fails to come on, remove the power supply to the receiver and wait for 30 seconds. Connect the power to the receiver and retest. If the RF indicator lamp (10) still does not come on, check the antenna connections and cable.



Antenna and Cable Check

Disconnect the antenna cable from the receiver. Use an ohmmeter set on the minimum resistance scale and check for continuity of the antenna cable leads. (See the following drawing.) There should be no continuity (maximum resistance reading) between A and B. There should be continuity between A and C (minimum resistance reading). There should be continuity between B and D. The antenna cable at point D should be grounded to the antenna mounting surface. There should be no contact between C and D or between C and "ground".



If the transmitter battery is good and the antenna assembly appears to be functioning correctly but a signal is not recognized by the receiver [RF indicator lamp (10) comes on when a signal is recognized], replace the transmitter and receiver or return the transmitter and receiver to DuraTech Industries.

Engine Shutdown Check

Once again press and hold the ENG button on the transmitter. The RF indicator lamp (10) and the master control indicator lamp (9) should come on. Also, the engine shutdown relay will close but there is not an indicator lamp to verify this. Visually observe the contacts in the engine shutdown relay to see that they open and close when you press and release the ENG button on the transmitter. Continuity can be checked by probing the engine shutdown terminal and the ground terminal while pressing and holding the ENG button on the transmitter. If there is continuity when you press the ENG button then this portion of the remote control is functioning properly.



Tub Forward and Tub Reverse Check

Press and release the TUB FWD button on the transmitter. The RF indicator lamp (10) and the tub forward indicator lamp (6) should come on. Press and release the TUB FWD button again and the RF indicator lamp (10) and the tub forward indicator lamp (6) should turn off. Press and release the TUB FWD button again and test the terminal strip to see if 12 volts DC is present by probing the tub forward terminal and the ground terminal. Press and release the TUB FWD button again so the indicator lamps turn off and no voltage should be present when probing the tub forward and ground terminals.

Press and release the TUB REV button on the transmitter. The RF indicator lamp (10) and the tub reverse indicator lamp (5) should come on. Press and release the TUB REV button again and the RF indicator lamp (10) and the tub reverse indicator lamp (5) should turn off. Press and release the TUB REV button again and test the terminal strip to see if 12 volts DC is present by probing the tub reverse terminal and the ground terminal. Press and release the TUB REV button again so the indicator lamps turn off and no voltage should be present when probing the tub reverse and ground terminals.



Press and release the TUB FWD button so lamp (6) is on. Press TUB REV once and lamp (6) should go off. Press TUB REV a second time and lamp (5) should come on. Press the TUB FWD button once and lamp (5) should turn off. Press TUB FWD again and lamp (6) should come on.

If all of the output functions appear to be operating correctly the wireless radio remote control is performing as expected. If problems continue, the cause may be in the wiring, connections, or components that the radio control operates.

If the problem appears to be in the radio control transmitter or receiver, replace both components or return both components to DuraTech Industries for repairs. Replacement transmitters (C band part no. 5700308 or D band part no. 5700257) can be obtained from DuraTech Industries to replace lost or damaged transmitters. Address codes can be matched to the existing radio receiver by removing the appropriate diodes from the transmitter circuit board to match your previous transmitter. **See figure 6.5.**



figure 6.3
 matching receiver and
 transmitter frequencies (for
 tub forward/reverse check
 refer to figure 6.2)



Replacement transmitters and receivers are sold only in matched sets so the address codes match correctly.

12V DC kit replacement radio kit part number is 5700224.



6.4 Troubleshooting Omnex Wireless Remote Controls

The OMNEX ORIGA is a portable, long range, programmable, 8-channel radio remote control unit for 10 to 32VDC operated fixed and mobile equipment. Designed as a safe, compact and easy-to-use radio remote control, the ORIGA puts complete control where it is needed most: with the operator.

TROUBLESHOOTING THE OMNEX ORIGA

THE REMOTE RADIO CONTROLLER (T100)/TRANSMITTER

SYMPTOM	POSSIBLE CAUSE	REMEDY
Flashing red LED	Battery power level is less than 20%	Replace batteries
Flashing red and yellow LEDs	T100(remote controller) is in Program mode	Press red button to close Program mode
Yellow LED does not flash when buttons 1-8 are pressed.	T100 not activated / Batteries are dead	Initiate appropriate power on sequence / Replace batteries
Yellow LED flashes when button is pressed, but machinery does not respond to the commands.	Out of Range	Relocate closer to the machinery

THE REMOTE RADIO RECEIVER (R100e)

SYMPTOM	POSSIBLE CAUSE	REMEDY
Out LED is extinguished	No power to the R100e (Receiver)	Check power source
SETUP Yellow LED illuminated	R100e is in Program mode	Allow R100e to timeout after 20 seconds
Green LINK LED does not flash when transmitter is ON	R100e does not have the correct ID - not likely on a new system - may occur where either the transmitter or the receiver is replaced individually	Initiate SETUP sequence - see "Programming a replacement transmitter".
STATUS Red LED is flashing	Incorrect input voltage	Check power source
STATUS Red LED is steady	Permanent internal fault	Disconnect R100e and return unit to manufacturer for repair
STATUS Green LED is flashing	Output shorted	Check wiring
Output LEDs do not light up when activated.	Output shorted	Check wiring, relays, and solenoids



PROGRAMMING A REPLACEMENT TRANSMITTER

To program a replacement transmitter, complete the following steps:

1. Power up the R100E Receiver and verify that the Green Status LED and the Red E-Stop LED are on steady.
2. Power up the T100 Transmitter into Programming Mode by Pressing and holding the RED E-Stop button and then the Green Power Button at the same time. This will power up the T100 into Programming Mode. The Yellow LED to the right of the GREEN Power Button will begin flashing slowly, (once per second).
3. Enter the Programming Password Code by pressing buttons (3, 1, 4, 2) and then press the GREEN Power button once. The Yellow LED to the right of the GREEN Power Button and the Red LED to the left of the GREEN Power button will begin flashing rapidly.
4. Enter the programming values. The programming values for DuraTech are 1266888888.
5. Press and hold the SETUP button on the R100E Receiver (approx. 5 sec.). The Yellow Setup LED will start flashing slowly while the R100E Receiver enters into programming mode. Once the Yellow Setup LED on the R100E Receiver begins to flash rapidly, release the SETUP button. The R100E is now ready to receive the programming information from the T100 Transmitter.
6. Press and release the GREEN Power Button on the T100 to start sending the Programming information to the R100E Receiver. The Green Link LED on the R100E Receiver will begin to flash, and the Green Status LED on the R100E Receiver will be ON steady. Wait for the Link LED to stop flashing, and for the Status LED to begin flashing. This signifies that the programming information has been successfully sent from the T100 Transmitter to the R100E Receiver.
7. Momentarily Power OFF the R100E Receiver and wait for 5 seconds, then power up the R100E Receiver again. The new program settings will now take effect.
8. Press the GREEN Power Button on the T100 Transmitter and observe that the Yellow LED to the right of the GREEN Power Button of the T100 Transmitter will begin flashing. Also note that the Green Link LED on the R100E Receiver is flashing and the Green Status LED on the R100E Receiver is on steady. You are now ready to operate your T100/R100E system.

OUT OF RANGE/LOSS OF SIGNAL




The range of the OMNEX ORIGA is approximately 1,200'. Under certain circumstances, such as low or dead batteries, loss of signal can occur within that distance. In the event that loss of signal occurs, the transmitter will shut off, and the engine will be shut off by the engine kill circuit.



REPLACING BATTERIES

Install batteries by removing the battery cover using a slotted screwdriver and inserting 4 "AA" Alkaline batteries. Orientation for batteries is embossed inside the battery housing.

WIRING SCHEMATIC FOR THE R100e RECEIVER





Appendix A: Warranty

DuraTech Industries International Inc. warrants to the original purchaser for 1 year from purchase date that this product will be free from defects in material and workmanship when used as intended and under normal maintenance and operating conditions. This warranty is limited to the replacement of any defective part or parts returned to our factory in Jamestown, North Dakota, USA, within thirty (30) days of failure.

This warranty shall become void if in the judgment of DuraTech Industries International, Inc. the machine has been subject to misuse, negligence, alterations, damaged by accident or lack of required normal maintenance, or if the product has been used for a purpose for which it was not designed.

All claims for warranty must be made through the dealer which originally sold the product and all warranty adjustments must be made through same.

This warranty does not apply to tires or bearings or any other trade accessories not manufactured by DuraTech Industries International Inc. Buyer must rely solely on the existing warranty, if any, of these respective manufacturers.

DuraTech Industries International Inc., shall **not** be held liable for damages of any kind, direct, contingent, or consequential to property under this warranty. DuraTech Industries International Inc., cannot be held liable for any damages resulting from causes beyond its control. DuraTech Industries International Inc., shall **not** be held liable under this warranty for rental costs or any expense or loss for labor or supplies.

DuraTech Industries International Inc., reserves the right to make changes in material and/or designs of this product at any time without notice.

This warranty is void if DuraTech Industries International Inc. does not receive a valid warranty registration card at its office in Jamestown, North Dakota, USA, within 10 days from date of original purchase.

All other warranties made with respect to this product, either expressed or implied, are hereby disclaimed by DuraTech Industries International Inc.





Appendix B: SPECIFICATIONS

General

Weight	10,600 lbs.
Transport Width	8'5"
Transport Height	10'8" (128")
Transport Length with folded conveyor	18'6" (222")
Axle	(1) - 12,000 lb. axle
Tires	(2) - 265 X 70R19.5
Brakes	Electric brakes
Tongue Weight	1,325 lbs.
Fuel Capacity	50 U.S. gallons
Hydraulic Oil Capacity	30 U.S. gallons
Lights	Clearance and directional

Tub features

Tub Width	7'8" - at the flare
Depth	40"
Tub Diameter at base	6'
Tub Wall	3/16" thick
Tub Drive	Hydraulic orbit motor direct drive to chain
Service Access	50° Hydraulic tilting tub
Discharge Conveyor	11' hydraulic top drive - 24" wide
Tub Speed Sensor	Electronic self-governing
Safety Switches	Safety shutdown
.....	Automatic shutdown if platform lifts while the rotor is spinning



Hammermill

Hammer Size	3/4" hardened swing hammers
Rotor - Shaft diameter	3" Stress proof steel
Rotor Length	26"
Rotor Plates	15-3/4" diameter x 1/2" thick
Feed Opening	27-1/2" x 24-3/4"
Screens	1/2" thick - avail. in various hole sizes
Hammer Rods	1-1/4" x 26" case hardened rods
Bearings	2-3/4" pillow block bearings
Hammermill Drive	Direct drive with torque limiter

Options

- Radio remote that features the following commands; tub start-stop, tub forward-reverse, tub cover motion, and emergency stop.
- Magnetic roller with aluminum deflector
- Engine block heater
- Tub cover



